

Programmable AC/DC Power Source

ASR-2000 Series

PROGRAMMING MANUAL



ISO-9001 CERTIFIED MANUFACTURER

GW INSTEK

This manual contains proprietary information, which is protected by copyright. All rights are reserved. No part of this manual may be photocopied, reproduced or translated to another language without prior written consent of Good Will company.

The information in this manual was correct at the time of printing. However, Good Will continues to improve products and reserves the rights to change specification, equipment, and maintenance procedures at any time without notice.

Table of Contents

S AFETY INSTRUCTIONS	4
G ETTING STARTED	8
ASR-2000 Series Overview	9
Appearance	12
R EMOTE CONTROL	21
Interface Configuration	22
Command Syntax	40
Command List	44
Status Register Overview	126
Error List	142
A PPENDIX	150
Factory Default Settings	150
I NDEX	161

S SAFETY INSTRUCTIONS

This chapter contains important safety instructions that you must follow during operation and storage. Read the following before any operation to ensure your safety and to keep the instrument in the best possible condition.

Safety Symbols

These safety symbols may appear in this manual or on the instrument.



WARNING

Warning: Identifies conditions or practices that could result in injury or loss of life.



CAUTION

Caution: Identifies conditions or practices that could result in damage to the ASR-2000 or to other properties.



DANGER High Voltage



Attention Refer to the Manual



Protective Conductor Terminal



Earth (ground) Terminal



Do not dispose electronic equipment as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased.

Safety Guidelines

General Guideline



CAUTION

- Do not place any heavy object on the ASR-2000.
- Avoid severe impact or rough handling that leads to damaging the ASR-2000.
- Do not discharge static electricity to the ASR-2000.
- Use only mating connectors, not bare wires, for the terminals.
- Do not block the cooling fan opening.
- Do not disassemble the ASR-2000 unless you are qualified.

(Measurement categories) EN 61010-1:2010 specifies the measurement categories and their requirements as follows. The ASR-2000 doesn't fall under category II, III or IV.

- Measurement category IV is for measurement performed at the source of low-voltage installation.
- Measurement category III is for measurement performed in the building installation.
- Measurement category II is for measurement performed on the circuits directly connected to the low voltage installation.
- 0 is for measurements performed on circuits not directly connected to Mains.

Power Supply



WARNING

- AC Input voltage range:
 - 100 ~ 240 Vac
 - Frequency: 47 ~ 63 Hz
 - To avoid electrical shock connect the protective grounding conductor of the AC power cord to an earth ground.
-

-
- | | |
|-----------------------|--|
| Cleaning the ASR-2000 | <ul style="list-style-type: none"> • Disconnect the power cord before cleaning. • Use a soft cloth dampened in a solution of mild detergent and water. Do not spray any liquid. • Do not use chemicals containing harsh material such as benzene, toluene, xylene, and acetone. |
|-----------------------|--|
-

- | | |
|-----------------------|---|
| Operation Environment | <ul style="list-style-type: none"> • Location: Indoor, no direct sunlight, dust free, almost non-conductive pollution (Note below) • Relative Humidity: 20%~ 80%, no condensation • Altitude: < 2000m • Temperature: 0°C to 40°C <p>(Pollution Degree) EN 61010-1:2010 specifies the pollution degrees and their requirements as follows. The ASR-2000 falls under degree 2.</p> <p>Pollution refers to “addition of foreign matter, solid, liquid, or gaseous (ionized gases), that may produce a reduction of dielectric strength or surface resistivity”.</p> <ul style="list-style-type: none"> • Pollution degree 1: No pollution or only dry, non-conductive pollution occurs. The pollution has no influence. • Pollution degree 2: Normally only non-conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation must be expected. • Pollution degree 3: Conductive pollution occurs, or dry, non-conductive pollution occurs which becomes conductive due to condensation which is expected. In such conditions, equipment is normally protected against exposure to direct sunlight, precipitation, and full wind pressure, but neither temperature nor humidity is controlled. |
|-----------------------|---|
-

- | | |
|---------------------|--|
| Storage environment | <ul style="list-style-type: none"> • Location: Indoor • Temperature: -10°C to 70°C • Relative Humidity: ≤90%, no condensation |
|---------------------|--|
-

Disposal



Do not dispose this instrument as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased. Please make sure discarded electrical waste is properly recycled to reduce environmental impact.

Power cord for the United Kingdom

When using the instrument in the United Kingdom, make sure the power cord meets the following safety instructions.


NOTE: This lead/appliance must only be wired by competent persons



WARNING: THIS APPLIANCE MUST BE EARTHED

IMPORTANT: The wires in this lead are coloured in accordance with the following code:

Green/ Yellow:	Earth
Blue:	Neutral
Brown:	Live (Phase)



As the colours of the wires in main leads may not correspond with the coloured marking identified in your plug/appliance, proceed as follows:

The wire which is coloured Green & Yellow must be connected to the Earth terminal marked with either the letter E, the earth symbol  or coloured Green/Green & Yellow.

The wire which is coloured Blue must be connected to the terminal which is marked with the letter N or coloured Blue or Black.

The wire which is coloured Brown must be connected to the terminal marked with the letter L or P or coloured Brown or Red.

If in doubt, consult the instructions provided with the equipment or contact the supplier.

This cable/appliance should be protected by a suitably rated and approved HBC mains fuse: refer to the rating information on the equipment and/or user instructions for details. As a guide, a cable of 0.75mm² should be protected by a 3A or 5A fuse. Larger conductors would normally require 13A types, depending on the connection method used.

Any exposed wiring from a cable, plug or connection that is engaged in a live socket is extremely hazardous. If a cable or plug is deemed hazardous, turn off the mains power and remove the cable, any fuses and fuse assemblies. All hazardous wiring must be immediately destroyed and replaced in accordance to the above standard.

GETTING STARTED

This chapter describes the ASR-2000 power supply in a nutshell, including its main features and front / rear panel introduction.

ASR-2000

• ASR-2000R



ASR-2000 Series Overview	9
Series lineup	9
Main Features	9
Accessories	10
Appearance	12
Front Panel	12
Rear Panel.....	18

ASR-2000 Series Overview

Series lineup

The ASR-2000 series consists of 4 models, the ASR-2050, ASR-2100, ASR-2050R and ASR-2100R, differing only in capacity and front panel output. Note that throughout the programming manual, the term “ASR-2000” refers to any of the models, unless stated otherwise.

Model Name	Power Rating	Max. Output Current	Max. Output Voltage
ASR-2050	500 VA	5 / 2.5 A	350 Vrms / 500 Vdc
ASR-2100	1000 VA	10 / 5 A	350 Vrms / 500 Vdc
ASR-2050R	500 VA	5 / 2.5 A	350 Vrms / 500 Vdc
ASR-2100R	1000 VA	10 / 5 A	350 Vrms / 500 Vdc

Main Features

- | | |
|-------------|---|
| Performance | <ul style="list-style-type: none">• Maximum AC output voltage is 350 Vrms• Maximum DC output voltage is 500 Vdc• Maximum output frequency is 999.9 Hz in AC mode• Supported AC+DC waveform application• DC full capacity output ability• Output voltage total harmonic distortion is less than 0.5% at all frequency• Crest factor reached 4 times high |
|-------------|---|

Features	• Include sine, square, triangle, arbitrary and DC output waveforms • Variable voltage, frequency and current limiter • Harmonic voltage and current analysis ability • Excellent and feature-rich measurement capacity • Sequence and simulate function • External input amplification • AC line synchronized output • Preset memory function • USB memory support • Remote sense • OCP, OPP and OTP protection function
----------	---

Interface	• Built-in LAN, USB host and USB device interface • External control I/O • External signal input • Factory option RS232 and GPIB interface
-----------	---

Accessories


Before using the ASR-2000 power source unit, check the package contents to make sure all the standard accessories are included.

Standard Accessories	Part number	Description
	CD ROM	User manual, programming manual
	82GW1SAFE0M*1	Safety guide
	Region dependent	Power cord
	63SC-XF101601 x 1	Mains terminal cover set

	63SC-XF101701 x 1	Remote sensing cover set
	GTL-123	Test leads: 1x red, 1x black
	GTL-246	USB CABLE (USB 2.0 Type A-Type B Cable, Approx. 1.2M)
Factory Installed Options	Part number	Description
	Optional 1	RS232 + GPIB interface
	Optional 2	European Output Socket
Optional Accessories	Part number	Description
	GET-003	Universal extended terminal box (ASR-2000R only)
	GET-004	EURO extended terminal box (ASR-2000R only)
	GRA-439-E	Rack mount adapter (EIA)
	GRA-439-J	Rack mount adapter (JIS)
	GTL-232	RS232C cable, approx. 2M
	GTL-258	An approximately 2M in length GPIB Cable including 25 pins Micro-D connector
	ASR-001	Air inlet filter
	ASR-002	External Three Phase Control Unit
Download	Name	Description
	gw_asr.inf	USB driver

Appearance

Front Panel





Item Index

Description

1	Power switch button
2	USB interface connector (A Type)
3	LCD screen
4	Display mode select key
5	Function keys (blue zone)
6	Lock/Unlock button
7	V/V-Limit button
8	F/F-Limit button
9	Irms/IPK-Limit button
A	Range key/Output mode key
B	Menu key/On phase key
C	Shift key



D	Test key/Output waveform key
E	Enter key
F	Preset key/Local mode key
G	Cancel key/ALM CLR key
H	Output key
I	Scroll wheel
J	Arrow keys
K	Air inlet
L	Hardcopy key
M	Output socket (ASR-2100/2050 only)

Item	Description	
Power Switch		Turn on the mains power
USB A Port		The USB port is used for data transfers and upgrading software. Also, it is available for screenshot hardcopy in association with the Hardcopy key.
 Note	It supports FAT32 format with maximum 32G storage only.	
LCD Screen	Displays the setting and measured values or menu system	
Display Mode Select Key		Selects between standard, simple and harmonic analysis mode

Function Keys



Assigned to the functions displayed on the right side of the screen




Lock/Unlock Key



Used to lock or unlock the front panel keys except output key. Simply press to lock, whilst long press to unlock.


Shift Key

Turns on the shift state, which enables shortcut operations with an icon **Shift** indicated on the top status bar. The shift state, which allows continuous shortcut operations, is kept until another press on shift key again.

Note

When performing shortcut operations, press shift key followed by another shortcut function key. Do not press both shift key and shortcut function key simultaneously.

V




Used for setting the output voltage

V-Limit



+



Used for setting the output voltage limit value

F




Used for setting the output frequency (DC mode N/A)




F-Limit




+



Used for setting the output frequency limit value (DC mode N/A)


Irms		Used for setting the maximum output current
IPK-Limit	 + 	Used to set the peak output current limit value
Range Key		Switches between the 100V, 200V and AUTO ranges
Output Mode	 + 	Selects between the AC+DC-INT, AC-INT, DC-INT, AC+DC-EXT, AC-EXT, AC+DC-ADD, AC-ADD, AC+DC-Sync and AC-Sync modes
Menu Key		Enters the Main menu or goes back to one of the display modes.
On Phase	 + 	Sets the on phase for the output voltage
Test Key		Puts the instrument into the Sequence and Simulation control mode.
Output Waveform	 + 	Selects between the Sine, Square, Triangle and ARB 1~16 waveforms (not available for DC-INT, AC+DC-EXT and AC-EXT)
Enter Key		Confirms selections and settings
Preset Key		Puts the instrument into Preset mode

Local Mode



Switches operation back to local mode from remote mode

Cancel Key



Used to cancel function setting menus or dialogs.

ALM CLR




Clears alarms

Hardcopy Key




Used to take a screenshot by simply one press on the key. Make sure an USB flash disk in well inserted before the action.

Output Key



Turns the output on or off.

Scroll Wheel




Used to navigate menu items or for increment/decrement values one step at a time.

Arrow Keys




The arrow keys are used to select the digit power of a value that is being edited

Air Inlet




Air inlet for cooling the inside of the ASR-2000 series

Output Socket







Output voltage socket, which has 2 versions in accordance with different regions: Universal and European types, in front panel. (only available for ASR-2100/2050)

Rear Panel




Item	Index	Description
------	-------	-------------

1		Line input
2		Output terminal
3		Remote sensing input terminal
4		Exhaust fan
5		External I/O connector
6		External signal input/ External synchronized signal input
7		USB interface connector (B Type)
8		Ethernet (LAN) connector
9		Optional 1 interfaces (RS232C & GPIB connectors)


Item	Description	
Line Input		AC inlet
Output Terminal		Output voltage terminal (M3 screw type, 10 ~ 18 AWG)
Remote Sensing Input Terminal		Compensation of load wire voltage drop. Only +S and –S are available for compensation. N.C. terminals are N/A. Refer to User Manual for details.
Exhaust Fan		The exhaust fan is used to expel the heat from the unit. Please ensure there is at least 20 cm distance between any object and the fan.
External Control I/O Connector		Used to control ASR-2000 externally by using the logic signal and monitor Sequence function status

External Signal
Input Connector




Synchronizing the output frequency with this external input signal for SYNC or outputting the amplified external signal with this external input signal for EXT and ADD.

USB




USB port for controlling the ASR-2000 remotely

Ethernet Port




The Ethernet port is used for remote control

RS232C
Connector



The optional RS232C connector for controlling the ASR-2000 remotely (Factory Installed Optional 1)

GPIB Connector
(25 pins Micro-D)



The optional GPIB connector for controlling the ASR-2000 remotely (Factory Installed Optional 1)

REMOTE CONTROL

This chapter describes basic configuration of IEEE488.2 based remote control.

Interface Configuration	22
Configure Ethernet Connection.....	22
USB Remote Interface	23
USB Remote Control Function Check.....	24
RS-232 Remote Interface (Optional 1).....	25
RS232 Remote Control Function Check.....	27
Using Realterm to Establish a Remote Connection	28
GPIB Remote Interface (Optional 1).....	31
GPIB Function Check	32
Web Server Remote Control Function Check	34
Socket Server Function Check	35
Command Syntax	40
Command List	44
Status Register Overview	126
Introduction to the Status Registers	126
The Status Registers	127
Questionable Status Register Group	128
Operation Status Register Group	131
Warning Status Register Group.....	133
System Lock Status Register Group	136
Standard Event Status Register Group	138
Status Byte Register & Service Request Enable Register ..	140
Error List	142
Command Errors	142
Execution Errors	145
Device Specific Errors	147
Query Errors.....	148

Interface Configuration


Configure Ethernet Connection

The Ethernet interface can be configured for a number of different applications. Ethernet can be configured for basic remote control or monitoring using a web server or it can be configured as a socket server.

The ASR-2000 supports both DHCP connections so the instrument can be automatically connected to an existing network or alternatively, network settings can be manually configured.

Ethernet Parameters	MAC Address (display only)	DHCP
	IP Address	Subnet mask
	Gateway	DNS address
	DNS Server	Socket port fixed at 2268

Ethernet Configuration

1. Connect a LAN cable from the PC to the Ethernet port on the rear panel. 
2. Press the *Menu* key. The Menu setting will appear on the display. 
3. Use the scroll wheel to go to item 3, *LAN* and press *Enter*.
4. If the LAN cable is installed correctly a connection is active, the *Connection Status* will show *Online*.
5. To automatically have the network assign an IP address, set DHCP to ON. Otherwise set DHCP to OFF to manually set the Ethernet settings.

DHCP	ON, OFF
------	---------

6. If DHCP was set to OFF, configure the remaining LAN parameters.

IP Address

Subnet Mask

Gateway


DNS Server

Socket Port



Note

Socket Port is fixed to 2268.



Exit

7. Press *Exit*[F4] to exit from the LAN settings.




USB Remote Interface

USB Configuration	PC side connector	Type A, host
	ASR-2000 side connector	Rear panel Type B, slave
	Speed	1.1/2.0 (full speed)
	USB Class	CDC (communications device class)

Steps

1. Connect the Type A-Type B USB cable from the PC to the rear panel USB B port.



2. Press the *Menu* key. The Menu setting will appear on the display. 
3. Use the scroll wheel to go to item 4, *USB Device*
4. If the connection is successful *Connection Status* will change from Offline to Online.
5. Press *Exit[F4]* to exit from the rear panel USB settings. 

Exit

USB Remote Control Function Check

Functionality Check

Invoke a terminal application such as Realterm.

ASR-2000 will appear as a COM port on the PC.

To check the COM settings in Windows, see the Device Manager. For example, in Win7 go to the Control panel → System → Hardware tab.



Note

If you are not familiar with using a terminal application to send/receive remote commands via a USB connection, please see page 28 for more information.

Run this query command via the terminal after the instrument has been configured for USB remote control (page 23).

*IDN?

This should return the Manufacturer, Model number, Serial number, and Software version in the following format.

GW-INSTEK,ASR-XXXX,GXXXXXXXXX, XX.XX

Manufacturer: GW-INSTEK

Model number : ASR-XXXX

Serial number : GXXXXXXXXX

Software version : XX.XX




Note

For further details, please see the programming manual, available on the GW Instek web site @ www.gwinstek.com.


RS-232 Remote Interface (Optional 1)

RS-232 Configuration	Connector	BD-9, male
	Parameters	Baud rate, data bits, parity, stop bits.

Pin Assignment	1 2 3 4 5	2: RxD (Receive data)
	6 7 8 9	3: TxD (Transmit data)
		5: GND
		4, 6 ~ 9: No connection




Pin Connection Use a Null Modem connection (RS-232C cable) as shown in the diagram below.



Steps

1. Connect the RS-232C cable from the PC to the rear panel RS-232 port.



2. Press the *Menu* key. The Menu setting will appear on the display.



3. Use the scroll wheel to go to item 5, RS232C and press *Enter*.
4. Set the RS232C relative settings.

Baud rate	1200, 2400, 4800, 9600(default), 19200, 38400, 57600, 115200,
Data bits	7 bits, 8 bits(default)
Parity	None(default), Odd, Even
Stop bits	1 bit(default), 2 bits

RS232C Configuration



Exit

5. Press *Exit*[F4] to exit from the RS232C settings.



Note

The standard accessory does Not include RS232 data cable. Please purchase the additional GTL-232 which will meet your need for RS232 connection.

RS232 Remote Control Function Check

Functionality Check

Invoke a terminal application such as Realterm.

For RS-232, set the COM port, baud rate, stop bit, data bit and parity accordingly.

To check the COM settings in Windows, see the Device Manager. For example, in Win7 go to the Control panel → System → Hardware tab.



Note

If you are not familiar with using a terminal application to send/receive remote commands from the serial port, please see page 28 for more information.

Run this query command via the terminal after the instrument has been configured for RS-232 remote control (page 25).

*IDN?

This should return the Manufacturer, Model number, Serial number, and Software version in the following format.

GW-INSTEK,ASR-XXXX,GXXXXXXXXX,XX.XX

Manufacturer: GW-INSTEK

Model number : ASR-XXXX

Serial number : GXXXXXXXXX

Software version : XX.XX



Note

For further details, please see the programming manual, available on the GW Instek web site @ www.gwinstek.com.

Using Realterm to Establish a Remote Connection

Background Realterm is a terminal program that can be used to communicate with a device attached to the serial port of a PC or via an emulated serial port via USB.

The following instructions apply to version 2.0.0.70. Even though Realterm is used as an example to establish a remote connection, any terminal program can be used that has similar functionality.



Note


Realterm can be downloaded on Sourceforge.net free of charge.

For more information please see
<http://realterm.sourceforge.net/>

- Operation**
1. Download Realterm and install according to the instructions on the Realterm website.
 2. Connect the ASR-2000 via USB (page 22) or via RS-232 (page 24).
 3. If using RS-232, make note of the configured baud rate, stop bits and parity.
 4. Go to the Windows device manager and find the COM port number for the connection. For example, go to the Start menu > Control Panel > Device Manager.

Double click the *Ports* icon to reveal the connected serial port devices and the COM port for the each connected device.

If using USB, the baud rate, stop bit and parity settings can be viewed by right-clicking the connected device and selecting the *Properties* option.



5. Start Realterm on the PC as an administrator.
Click:
Start menu>All Programs>RealTerm>realterm


Tip: to run as an administrator, you can right click the Realterm icon in the Windows Start menu and select the *Run as Administrator* option.

6. After Realterm has started, click on the *Port* tab.

Enter the *Baud*, *Parity*, *Data bits*, *Stop bits* and *Port* number configuration for the connection.

The *Hardware Flow Control*, *Software Flow Control* options can be left at the default settings.

7. Press *Open* to connect to the ASR-2000.



Note

For USB, the baud rate should be fixed to 115,200.


8. Click on the *Send* tab.

In the *EOL* configuration, check on the *+LF* check boxes.

Enter the query:

**idn?*

Click on *Send ASCII*.



9. The terminal display will return the following:


GW-INSTEK,ASR-XXXX,GXXXXXXXXX,XX.XX
(manufacturer, model, serial number, software version)

10. If Realterm fails to connect to the ASR-2000, please check all the cables and settings and try again.

GPIB Remote Interface (Optional 1)

GPIB Configuration

1. Connect a GPIB cable from the PC to the GPIB port on the rear panel.



2. Press the *Menu* key. The Menu setting will appear on the display.




3. Use the scroll wheel to go to item 6, *GPIB* and press *Enter*.

4. Set the GPIB address.

GPIB Address 0 ~ 30 (10 by default)

GPIB Configuration



Note

Only one GPIB address can be used at a time.

Exit

5. Press *Exit*[F4] to exit from the GPIB settings.



- GPIB Constraints
- Maximum 15 devices altogether, 20m cable length, 2m between each device
 - Unique address assigned to each device
 - At least 2/3 of the devices turned On
 - No loop or parallel connection



Note

The standard accessory does Not include GPIB data cable. Please purchase the additional GTL-258 which will meet your need for GPIB connection.

GPIB Function Check

Functionality
Check

Please use the National Instruments Measurement & Automation Controller software to confirm GPIB/LAN functionality.

See the National Instrument website,
<http://www.ni.com> for details.



Note


- For further details, please see the programming manual, available on the GW Instek web site @ www.gwinstek.com
- Operating System: Windows XP, 7, 8, 10

Operation


1. Start the NI Measurement and Automation Explorer (MAX) program. Using Windows, press:



Start>All Programs>NI MAX



2. From the Configuration panel access;
My System>Devices and Interfaces>GPIB0
3. Press the *Scan for Instruments* button.
4. In the *Connected Instruments* panel the ASR-2000 should be detected as *Instrument 0* with the address the same as that configured on the ASR-2000.
5. Double click the *Instrument 0* icon.




6. Click on *Communicate with Instrument*.
7. Under the Communicator tab, ensure **IDN?* is written in the *Send String* text box.

8. Click on the *Query* button to send the *IDN? query to the instrument.
9. The instrument identification string will be returned to the buffer area:

GW-INSTEK,ASR-XXXX,GXXXXXXXXX,XX.XX

(manufacturer, model, serial number, software version)



10. The function check is complete.

Web Server Remote Control Function Check

Functionality Check

Enter the IP address of the power supply (for example: [http:// XXX.XXX.XXX.XXX](http://XXX.XXX.XXX.XXX)) in a web browser after the instrument has been configured for LAN (page 22).

The web interface allows you to:

- View the system and information and the network configuration.
- View the analog control pinout.

- View the dimensions of the unit.
- View the operating area

Example:

The screenshot shows the GW INSTEK web interface. At the top, there is a header with the GW INSTEK logo, the tagline "Simply Reliable", a "Visit Our Site" link, and "Support" and "Contact Us" links. Below the header, there is a navigation menu with links to "Welcome Page", "Network Configuration", "Analog Control", "Figure of Dimensions", and "Operating Area". The "Network Configuration" section is active, showing fields for IP Address (192.168.0.145), Subnet Mask (255.255.255.0), Gateway (192.168.0.1), DNS (172.16.1.252), and DHCP State (radio buttons for ON and OFF, with OFF selected). There is also a "Password" field and a "Submit" button.


Socket Server Function Check

Background To test the socket server functionality, National Instruments Measurement and Automation Explorer can be used. This program is available on the NI website, www.ni.com, via a search for the VISA Run-time Engine page, or “downloads” at the following URL, <http://www.ni.com/visa/>

Requirements Operating System: Windows XP, 7, 8, 10

Functionality Check 1. Start the NI Measurement and Automation Explorer (MAX) program. Using Windows, press:


Start>All Programs>NI MAX




2. From the Configuration panel access;

My System>Devices and Interfaces>Network Devices


3. Press *Add New Network Device>Visa TCP/IP Resource...*



4. Select *Manual Entry of Raw Socket* from the popup window.




5. Enter the IP address and the port number of the ASR-2000. The port number is fixed at 2268.
6. Double click the Validate button and press *Next*.




7. Next configure the Alias (name) of the ASR-2000 connection. In this example the Alias is: ASR

8. Click finish.




9. The IP address of the power supply will now appear under Network Devices in the configuration panel. Select this icon now.

10. Press *Open VISA Test Panel*.




11. Click the *Configuration* Icon. Under the *IO Settings* tab check *Enable Termination Character*. The termination character should be set as *Line Feed - \n*.



12. Click the *Input/Output* icon. Under the *Basic I/O* tab, make sure **IDN?\n* is entered in the *Select or Enter Command* drop box.

13. Click *Query*.

The ASR-2000 will return the machine identification string into the buffer area:
GW-INSTEK,ASR-XXXX,GXXXXXXXXX,XX.XX



Note


For further details, please see the programming manual, available on the GW Instek web site @ www.gwinstek.com.

Command Syntax

Compatible Standard	IEEE488.2	Partial compatibility
	SCPI, 1999	Partial compatibility

Command Structure SCPI commands follow a tree-like structure, organized into nodes. Each level of the command tree is a node. Each keyword in a SCPI command represents each node in the command tree. Each keyword (node) of a SCPI command is separated by a colon (:).

For example, the diagram below shows an SCPI sub-structure and a command example.



Command types There are a number of different instrument commands and queries. A command sends instructions or data to the unit and a query receives data or status information from the unit.

Command types

Simple	A single command with/without a parameter
Example	*IDN?

Query	A query is a simple or compound command followed by a question mark (?). A parameter (data) is returned.
Example	meas:curr?
Compound	Two or more commands on the same command line. Compound commands are separated with either a semi-colon (;) or a semi-colon and a colon (;:).
	A semi-colon is used to join two related commands, with the caveat that the last command must begin at the last node of the first command.
Example	meas:volt?;curr?
	A semi-colon and colon are used to combine two commands from different nodes.
Example	meas:volt?::sour:volt?
 Note (Further explanation)	A semi-colon(;) is used to connect two commands. A colon(:) at the start of a command indicates that the command starts from the root node. The first command can ignore that first colon. Any commands after the first command (for compound commands) that do not begin with a colon, must begin at the last node of the first command.

Command Forms Commands and queries have two different forms, long and short. The command syntax is written with the short form of the command in capitals and the remainder (long form) in lower case.

The commands can be written in capitals or lower-case, just so long as the short or long forms are complete. An incomplete command will not be recognized.

Below are examples of correctly written commands.


Long form :SYSTem:ERRor?
 :SYSTEM:ERROR?
 :system:error?

Short form SYST:ERR?
 syst:err?

Square Brackets Commands that contain square brackets indicate that the contents are optional. The function of the command is the same with or without the square bracketed items, as shown below.

For example the query “:OUTPut[:STATe]?” has two valid forms, “:OUTPut:STATe?” and “:OUTPut?”.

**Command
Format**



1. Command header
 2. Space
 3. Parameter 1
 4. Comma (no space before/after comma)
 5. Parameter 2
-

Parameters

Type	Description	Example
<Boolean>	Boolean logic	0, 1

	<NR1>	integers	0, 1, 2, 3
	<NR2>	decimal numbers	0.1, 3.14, 8.5
	<NR3>	floating point	4.5e-1, 8.25e+1
	<NRf>	any of NR1, 2, 3	1, 1.5, 4.5e-1
	<block data>	Definitive length arbitrary block data. A single decimal digit followed by data. The decimal digit specifies how many 8-bit data bytes follow.	

Message Terminator	LF	Line feed code	
--------------------	----	----------------	--

Command List

Common Commands	*CLS.....	50
	*ESE	50
	*ESR.....	51
	*IDN	51
	*OPC.....	51
	*RCL	52
	*RST	52
	*SAV	52
	*SRE.....	53
	*STB	53
	*WAI.....	53
Data/Trace Commands	:DATA TRACe:SEQuence:CLEar	54
	:DATA TRACe:SEQuence:RECall	54
	:DATA TRACe:SEQuence:STORe	55
	:DATA TRACe:SIMulation:CLEar.....	55
	:DATA TRACe:SIMulation:RECall.....	56
	:DATA TRACe:SIMulation:STORe.....	56
	:DATA TRACe:WAVe:CLEar.....	56
Measure Commands	:DATA TRACe:WAVe[:DATA]	57
	:MEASure[:SCALar]:CURRent:CFACtor	58
	:MEASure[:SCALar]:CURRent:HIGH	58
	:MEASure[:SCALar]:CURRent:LOW	59
	:MEASure[:SCALar]:CURRent:PEAK:CLEar	59
	:MEASure[:SCALar]:CURRent:PEAK:HOLD	59
	:MEASure[:SCALar]:CURRent[:RMS]	59
	:MEASure[:SCALar]:CURRent:AVERage	60
	:MEASure[:SCALar]:CURRent:HARMonic[:RMS] ...	60
	:MEASure[:SCALar]:CURRent:HARMonic:RATio...	60
	:MEASure[:SCALar]:FREQuency	60
	:MEASure[:SCALar]:POWEr[:AC]:APParent	61
	:MEASure[:SCALar]:POWEr[:AC]:PFACtor.....	61
	:MEASure[:SCALar]:POWEr[:AC]:REACTiVe.....	61

	:MEASure[:SCALar]:POWer[:AC][:REAL]	61
	:MEASure[:SCALar]:VOLTag[:RMS]	61
	:MEASure[:SCALar]:VOLTag:AVERage	62
	:MEASure[:SCALar]:VOLTag:HIGH	62
	:MEASure[:SCALar]:VOLTag:LOW	62
	:MEASure[:SCALar]:VOLTag:HARMonic[:RMS]....	62
	:MEASure[:SCALar]:VOLTag:HARMonic:RATio ...	63
	:MEASure:CONFigure:SENSing	63
Memory	:MEMory:RCL	64
Commands	:MEMory:SAV	64
Output	:OUTPut[:STATe]	65
Commands	:OUTPut:PON	65
	:OUTPut:PROTection:CLEar	66
	:OUTPut:RELAy	66
Status	:STATus:OPERation:CONDition.....	67
Commands	:STATus:OPERation:ENABle.....	68
	:STATus:OPERation[:EVENT]	68
	:STATus:OPERation:NTRansition.....	68
	:STATus:OPERation:PTRansition	68
	:STATus:QUEStionable[:EVENT]	69
	:STATus:QUEStionable:CONDition	69
	:STATus:QUEStionable:ENABle	69
	:STATus:QUEStionable:NTRansition	70
	:STATus:QUEStionable:PTRansition	70
	:STATus:PRESet.....	70
	:STATus:WARning:CONDition	71
	:STATus:WARning:ENABle.....	71
	:STATus:WARning[:EVENT]	72
	:STATus:WARning:NTRansition	72
	:STATus:WARning:PTRansition	72
	:STATus:LOCK:CONDition.....	73
	:STATus:LOCK:ENABle	73
	:STATus:LOCK[:EVENT]	73
	:STATus:LOCK:NTRansition.....	73

	:STATus:LOCK:PTRansition.....	74
System	:SYSTem:BEEPer:STATe.....	76
Commands	:SYSTem:COMMunicate:GPIB[:SELF]:ADDRes	76
	:SYSTem:COMMunicate:LAN:DHCP	76
	:SYSTem:COMMunicate:LAN:DNS	77
	:SYSTem:COMMunicate:LAN:GATeway	77
	:SYSTem:COMMunicate:LAN:IPADdress.....	77
	:SYSTem:COMMunicate:LAN:MAC	78
	:SYSTem:COMMunicate:LAN:SMASk.....	78
	:SYSTem:COMMunicate:RLSTate	79
	:SYSTem:COMMunicate:SERial[:RECeive]	
	:TRANsmit:BAUD	79
	:SYSTem:COMMunicate:SERial[:RECeive]	
	:TRANsmit:BITS	80
	:SYSTem:COMMunicate:SERial[:RECeive]	
	:TRANsmit:PARity	80
	:SYSTem:COMMunicate:SERial[:RECeive]	
	:TRANsmit:SBITs	81
	:SYSTem:COMMunicate:TCPIP:CONTRol	82
	:SYSTem:COMMunicate:USB:FRONT:STATe.....	82
	:SYSTem:COMMunicate:USB:REAR:STATe	82
	:SYSTem:CONFigure[:MODE]	82
	:SYSTem:CONFigure:EXTio[:STATe]	83
	:SYSTem:ERRor	83
	:SYSTem:ERRor:ENABle	84
	:SYSTem:HOLD:STATe	84
	:SYSTem:IPKHold:TIME	84
	:SYSTem:KLOCK	84
	:SYSTem:REBoot	85
	:SYSTem:SLEW:MODE.....	85
	:SYSTem:VUNit	85
Source	[:SOURce]:CURRent:LIMit:PEAK:HIGH	87
Commands	[:SOURce]:CURRent:LIMit:PEAK:LOW	88
	[:SOURce]:CURRent:LIMit:RMS[:AMPLitude]..	88
	[:SOURce]:CURRent:LIMit:PEAK:MODE	89
	[:SOURce]:CURRent:LIMit:RMS:MODE.....	89

	[:SOURce]:FREQuency:LIMit:HIGH	90
	[:SOURce]:FREQuency:LIMit:LOW	90
	[:SOURce]:FREQuency[:IMMediate]	91
	[:SOURce]:FUNCTion[:SHAPE][:IMMediate]	91
	[:SOURce]:FUNCTion:THD:FORMat	92
	[:SOURce]:MODE	93
	[:SOURce]:PHASe:STARt:STATe	94
	[:SOURce]:PHASe:STOP:STATe.....	94
	[:SOURce]:PHASe:STARt[:IMMediate]	95
	[:SOURce]:PHASe:STOP[:IMMediate]	95
	[:SOURce]:READ	96
	[:SOURce]:VOLTage:RANGe	96
	[:SOURce]:VOLTage:LIMit:RMS	97
	[:SOURce]:VOLTage:LIMit:PEAK.....	97
	[:SOURce]:VOLTage:LIMit:HIGH.....	98
	[:SOURce]:VOLTage:LIMit:LOW	98
	[:SOURce]:VOLTage[:LEVel][:IMMediate] [:AMPLitude]	99
	[:SOURce]:VOLTage[:LEVel][:IMMediate] :OFFSet.....	99
Sequence Commands	[:SOURce]:SEQUence:CPARameter	101
	[:SOURce]:SEQUence:CSTep.....	102
	[:SOURce]:SEQUence:SPARameter	102
	[:SOURce]:SEQUence:STEP	103
	[:SOURce]:SEQUence:CONDition	104
	:TRIGger:SEQUence:SELected:EXECute	104
Simulate Commands	[:SOURce]:SIMulation:CONDition	107
	[:SOURce]:SIMulation:ABNormal:CODE	107
	[:SOURce]:SIMulation:ABNormal:FREQuency.	108
	[:SOURce]:SIMulation:ABNormal:PHASe :STARt:ENABle.....	108
	[:SOURce]:SIMulation:ABNormal:PHASe :STARt[:IMMediate]	109
	[:SOURce]:SIMulation:ABNormal:PHASe :STOP:ENABle	109
	[:SOURce]:SIMulation:ABNormal:PHASe	

:STOP[:IMMediate]	110
[:SOURce]:SIMulation:ABNormal:TIME	110
[:SOURce]:SIMulation:ABNormal:VOLTage....	111
[:SOURce]:SIMulation:CSTep	111
[:SOURce]:SIMulation:INITial:CODE.....	112
[:SOURce]:SIMulation:INITial:FREQuency	112
[:SOURce]:SIMulation:INITial:PHASe	
:START:ENABle.....	113
[:SOURce]:SIMulation:INITial:PHASe	
:START[:IMMediate]	113
[:SOURce]:SIMulation:INITial:PHASe	
:STOP:ENABle	114
[:SOURce]:SIMulation:INITial:PHASe	
:STOP[:IMMediate]	114
[:SOURce]:SIMulation:INITial:VOLTage	115
[:SOURce]:SIMulation:NORMal<1 2>:CODE ..	115
[:SOURce]:SIMulation:NORMal1:FREQuency ..	116
[:SOURce]:SIMulation:NORMal<1 2>	
:PHASe:START:ENABle	116
[:SOURce]:SIMulation:NORMal<1 2>	
:PHASe:START[:IMMediate]	117
[:SOURce]:SIMulation:NORMal<1 2>	
:PHASe:STOP:ENABle	117
[:SOURce]:SIMulation:NORMal<1 2>	
:PHASe:STOP[:IMMediate].....	118
[:SOURce]:SIMulation:NORMal<1 2>:TIME....	118
[:SOURce]:SIMulation:NORMal1:VOLTage.....	119
[:SOURce]:SIMulation:REPeat:COUNt	119
[:SOURce]:SIMulation:REPeat:ENABle.....	120
[:SOURce]:SIMulation:TRANsition<1 2>	
:TIME.....	120
[:SOURce]:SIMulation:TRANsition<1 2>	
:CODE	121
:TRIGger:SIMulation:SELected:EXECute.....	121
Input Commands :INPut:GAIN	122
:INPut:SYNC:SOURce	122

Display	:DISPlay[:WINDow]:DESIgn:MODE	124
Commands	:DISPlay[:WINDow]:MEASure	
	:SOURce<1 2 3>	124

Common Commands

*CLS.....	50
*ESE	50
*ESR.....	51
*IDN	51
*OPC.....	51
*RCL	52
*RST	52
*SAV	52
*SRE.....	53
*STB	53
*WAI	53

*CLS

Set →

Description	The *CLS command clears all the event registers, including the status byte, event status and error queue.
-------------	---

Syntax	*CLS
--------	------

*ESE

Set →

→ Query

Description	Sets or queries the Standard Event Status Enable register.
-------------	--

Syntax	*ESE <NR1>
--------	------------

Query Syntax	*ESE?
--------------	-------

Parameter	<NR1>	0~255
-----------	-------	-------

Return parameter	<NR1>	Returns the bit sum of the Standard Event Status Enable register.
------------------	-------	---

***ESR**

→ Query

Description	Queries the Standard Event Status (Event) register. The Event Status register is cleared after it is read.
-------------	--

Query Syntax	*ESR?
--------------	-------

Return parameter	<NR1>	Returns the bit sum of the Standard Event Status (Event) register and clears the register.
------------------	-------	--

***IDN**

→ Query

Description	Queries the manufacturer, model name, serial number, and firmware version of the ASR.
-------------	---

Query Syntax	*IDN?
--------------	-------

Return parameter	<string>	Returns the instrument identification as a string in the following format: GW-INSTEK,ASR-XXXX,GXXXXXXXXX,XX.XX Manufacturer: GW-INSTEK Model number : ASR-XXXX Serial number : GXXXXXXXXX Firmware version : XX.XX
------------------	----------	---

***OPC**

→ Query

Description	The *OPC? Query returns 1 when all the outstanding commands have completed.
-------------	---

Query Syntax	*OPC?
--------------	-------

Return parameter	1	Returns 1 when all the outstanding commands have completed.
------------------	---	---

***RCL**

Set →

Description	Recalls the contents stored in memory slot M0 ~ M9. These memory slots are mapped to the preset settings.	
Syntax	*RCL {<NR1> MINimum MAXimum}	
Parameter	<NR1>	0 ~ 9 (as memory M0 ~ M9)
	MIN	Recalls the M0 memory contents.
	MAX	Recalls the M9 memory contents.

***RST**

Set →

Description	Performs a device reset. Configures the unit to a known configuration (default settings). This known configuration is independent of the usage history.	
Syntax	*RST	

***SAV**

Set →

Description	Saves the settings into memory slot M0 ~ M9. These memory slots are mapped to the preset settings.	
Syntax	*SAV {<NR1> MINimum MAXimum}	
Return parameter	<NR1>	0 ~ 9 (as memory M0 ~ M9)
	MIN	Saves to the M0 memory slot.
	MAX	Saves to the M9 memory slot.

***SRE**

Set →
→ Query

Description	Sets or queries the Service Request Enable register. The Service Request Enable register determines which registers of the Status Byte register are able to generate service requests.	
Syntax	*SRE <NR1>	
Query Syntax	*SRE?	
Parameter	<NR1>	0~255
Return parameter	<NR1>	Returns the bit sum of the Service Request Enable register.

***STB**

→ Query

Description	Queries the bit sum of the Status Byte register with MSS (Master summary Status) replacing the RQS bit (bit 6).	
Query Syntax	*STB?	
Return parameter	<NR1>	Returns the bit sum of the Status Byte register with the MSS bit (bit 6).

***WAI**

Set →

Description	Prevents any other commands or queries from being executed until all outstanding commands have completed.	
Syntax	*WAI	

Trace/Data Commands



Note

The TRACE and DATA node for the following commands are functionally equivalent.

:DATA TRACe:SEQuence:CLEar	54
:DATA TRACe:SEQuence:RECall	54
:DATA TRACe:SEQuence:STORe	55
:DATA TRACe:SIMulation:CLEar.....	55
:DATA TRACe:SIMulation:RECall.....	56
:DATA TRACe:SIMulation:STORe.....	56
:DATA TRACe:WAVe:CLEar	56
:DATA TRACe:WAVe[:DATA]	57

:DATA|TRACe:SEQuence:CLEar



Description	Clears the sequence data for the selected save memory (Seq0 ~ Seq9).	
Syntax	:DATA TRACe:SEQuence:CLEar {<NR1> MINimum MAXimum}	
Parameter	<NR1>	0~9
	MIN	0
	MAX	9
Example	:DATA:SEQ:CLE 1 Clears the sequence data from Seq1.	

:DATA|TRACe:SEQuence:RECall



Description	Loads the sequence data. This command is the equivalent to recalling a sequence memory in the Sequence mode.	
Syntax	:DATA TRACe:SEQuence:RECall {<NR1> MINimum MAXimum}	

Parameter	<NR1>	0~9 (Seq0 ~ Seq9).
	MIN	0
	MAX	9
Example	:DATA:SEQ:REC 1	
	Loads the data from Seq1.	

:DATA|TRACe:SEQuence:STORe

Set →

Description	Saves the sequence data. This command is the equivalent to saving a sequence memory in Sequence mode.	
Syntax	:DATA TRACe:SEQuence:STORe {<NR1> MINimum MAXimum}	
Parameter	<NR1>	0~9 (Seq0 ~ Seq9).
	MIN	0
	MAX	9
Example	:DATA:SEQ:STOR 1 Saves the data from Seq1.	

:DATA|TRACe:SIMulation:CLEAr

Set →

Description	Clears the simulation data for the selected save memory (SIM0 ~ SIM9).	
Syntax	:DATA TRACe:SIMulation:CLEAr {<NR1> MINimum MAXimum}	
Parameter	<NR1>	0~9 (SIM0 ~ SIM9).
	MIN	0
	MAX	9
Example	:DATA:SIM:CLE 1 Clears the simulation data from SIM1.	

:DATA|TRACe:SIMulation:RECall

Set →

Description	Loads the simulation data. This command is the equivalent to recalling a simulation memory in the Simulation mode (SIM0~SIM9).						
Syntax	:DATA TRACe:SIMulation:RECall {<NR1> MINimum MAXimum}						
Parameter	<table> <tr> <td><NR1></td><td>0~9 (SIM0 ~ SIM9).</td></tr> <tr> <td>MIN</td><td>0</td></tr> <tr> <td>MAX</td><td>9</td></tr> </table>	<NR1>	0~9 (SIM0 ~ SIM9).	MIN	0	MAX	9
<NR1>	0~9 (SIM0 ~ SIM9).						
MIN	0						
MAX	9						
Example	:DATA:SIM:REC 1 Loads the data from SIM1.						

:DATA|TRACe:SIMulation:STORe

Set →

Description	Saves the simulation data. This command is the equivalent saving a simulation memory in Simulation mode (SIM0 ~ SIM9).						
Syntax	:DATA TRACe:SIMulation:STORe {<NR1> MINimum MAXimum}						
Parameter	<table> <tr> <td><NR1></td><td>0~9 (SIM0 ~ SIM9).</td></tr> <tr> <td>MIN</td><td>0</td></tr> <tr> <td>MAX</td><td>9</td></tr> </table>	<NR1>	0~9 (SIM0 ~ SIM9).	MIN	0	MAX	9
<NR1>	0~9 (SIM0 ~ SIM9).						
MIN	0						
MAX	9						
Example	:DATA:SIM:STOR 1 Saves the data from SIM1.						

:DATA|TRACe:WAVE:CLEar

Set →

Description	Clears the ARB 1-16 data for the selected wave group.
Syntax	:DATA TRACe:WAVE:CLEar {<NR1> MINimum MAXimum}

Parameter	<NR1>	1~16 (ARB1 ~ ARB16).
	MIN	1(1ARB1)
	MAX	16(ARB16)
Example	:DATA:WAV:CLE 13 Clears the wave data from ARB13.	

:DATA|TRACe:WAVe[:DATA]



Description	Sets the arbitrary wave.	
Syntax	:DATA TRACe:WAVe[:DATA] {<NR1> <Binary Data>}	
Parameter	<NR1>	1 – 16 (ARB 1 – 16)
	Binary Data includes the #48192<DAB>...<DAB>	
	#	Indicates the block data is sent.
	4	Indicates the number of subsequent numbers.
	8192	Indicates the number of subsequent byte data.
	<DAB>.. <DAB>	Indicates 16-bit with 4096 words waveform data. Plus, the data format of wave is the big endian in the form of two's complement.
Example	TRAC:WAV 1, #48192<DAB>...<DAB>	

Measure Commands

:MEASure[:SCALar]:CURRent:CFACtor	58
:MEASure[:SCALar]:CURRent:HIGH	58
:MEASure[:SCALar]:CURRent:LOW	59
:MEASure[:SCALar]:CURRent:PEAK:CLEAr	59
:MEASure[:SCALar]:CURRent:PEAK:HOLD	59
:MEASure[:SCALar]:CURRent[:RMS]	59
:MEASure[:SCALar]:CURRent:AVERAge	60
:MEASure[:SCALar]:CURRent:HARMonic[:RMS] ...	60
:MEASure[:SCALar]:CURRent:HARMonic:RATio...	60
:MEASure[:SCALar]:FREQuency	60
:MEASure[:SCALar]:POWEr[:AC]:APParent	61
:MEASure[:SCALar]:POWEr[:AC]:PFACtor	61
:MEASure[:SCALar]:POWEr[:AC]:REACtive	61
:MEASure[:SCALar]:POWEr[:AC][:REAL]	61
:MEASure[:SCALar]:VOLTage[:RMS]	61
:MEASure[:SCALar]:VOLTage:AVERAge	62
:MEASure[:SCALar]:VOLTage:HIGH	62
:MEASure[:SCALar]:VOLTage:LOW	62
:MEASure[:SCALar]:VOLTage:HARMonic[:RMS]....	62
:MEASure[:SCALar]:VOLTage:HARMonic:RATio ...	63
:MEASure:CONFigure:SENSing	63

:MEASure[:SCALar]:CURRent:CFACtor →(Query)

Description	Returns the output current crest factor (CF).
-------------	---

Query syntax	:MEASure[:SCALar]:CURRent:CFACtor?
--------------	------------------------------------

Return parameter	<NR2>	Returns the crest factor.
------------------	-------	---------------------------

:MEASure[:SCALar]:CURRent:HIGH →(Query)

Description	Returns the output current maximum peak value (Imax).
-------------	---

Note: Current maximum peak value is defined as the highest peak value in the complete period.

Query syntax :MEASure[:SCALar]:CURRent:HIGH?

Return parameter <NR2> Returns the I_{max} value in amps.

:MEASure[:SCALar]:CURRent:LOW

→ Query

Description Returns the output current minimum value (I_{min}).



Note

Current minimum value is defined as the lowest value in the complete period.

Query syntax :MEASure[:SCALar]:CURRent:LOW?

Return parameter <NR2> Returns the I_{min} value in amps.

:MEASure[:SCALar]:CURRent:PEAK:CLEar

Set →

Description Clears the current peak-hold value.

Syntax :MEASure[:SCALar]:CURRent:PEAK:CLEar

:MEASure[:SCALar]:CURRent:PEAK:HOLD

→ Query

Description Returns the current peak hold value in amps (IPK Hold).

Query syntax :MEASure[:SCALar]:CURRent:PEAK:HOLD?

Return <NR2> Returns the peak hold value in amps.

:MEASure[:SCALar]:CURRent[:RMS]

→ Query

Description Returns the output current (I_{rms}).

Query syntax :MEASure[:SCALar]:CURRent[:RMS]?

Return <NR2> Returns the current value in I_{rms}.

:MEASure[:SCALar]:CURRent:AVERage → **Query**

Description	Returns the current average value (Iavg).	
Query syntax	:MEASure[:SCALar]:CURRent:AVERage?	
Return	<NR2>	Returns the current average value in amps.

:MEASure[:SCALar]:CURRent:HARMonic[:RMS] → **Query**

Description	Returns 41 values covering Total and order 1 to 40 current (Irms) in harmonic. (Only AC-INT and 50 /60 Hz Active)	
Query syntax	:MEASure[:SCALar]:CURRent:HARMonic[:RMS]?	
Return	<NR2>,<NR2>,<NR2>,<NR2>..., etc.	Returns the entire 41 values containing Total and order 1 to 40 current (Irms) in harmonic.

:MEASure[:SCALar]:CURRent:HARMonic:RATio → **Query**

Description	Returns 41 values covering Total and order 1 to 40 current (Ratio) in harmonic. (Only AC-INT and 50 /60 Hz Active)	
Query syntax	:MEASure[:SCALar]:CURRent:HARMonic:RATio?	
Return	<NR2>,<NR2>,<NR2>,<NR2>..., etc.	Returns the entire 41 values containing Total and order 1 to 40 current (Ratio) in harmonic.

:MEASure[:SCALar]:FREQuency → **Query**

Description	Returns the SYNC signal source frequency in Hz. (Only AC+DC-sync or AC-sync Active)	
Query syntax	:MEASure[:SCALar]:FREQuency?	
Return	<NR2>	Returns the SYNC frequency in Hz.

:MEASure[:SCALar]:POWer[:AC]:APParent → Query

Description	Returns the apparent power (S).
Query syntax	:MEASure[:SCALar]:POWer[:AC]:APParent?
Return	<NR2> Returns the apparent power in VA.

:MEASure[:SCALar]:POWer[:AC]:PFACtor → Query

Description	Returns the power factor (PF).
Query syntax	:MEASure[:SCALar]:POWer[:AC]:PFACtor?
Return	<NR2> Returns the power factor.

:MEASure[:SCALar]:POWer[:AC]:REACtive → Query

Description	Returns the reactive power (Q).
Query syntax	:MEASure[:SCALar]:POWer[:AC]:REACtive?
Return	<NR2> Returns the reactive power in VAR.

:MEASure[:SCALar]:POWer[:AC][:REAL] → Query

Description	Returns the active power in Watts (P).
Query syntax	:MEASure[:SCALar]:POWer[:AC][:REAL]?
Return	<NR2> Returns the power in Watts.

:MEASure[:SCALar]:VOLTage[:RMS] → Query

Description	Returns the voltage (Vrms).
Query syntax	:MEASure[:SCALar]:VOLTage[:RMS]?
Return	<NR2> Returns the voltage value in Vrms.

:MEASure[:SCALar]:VOLTage:AVERage →(Query)

Description	Returns the voltage average value (Vavg).
Query syntax	:MEASure[:SCALar]:VOLTage:AVERage?
Return	<NR2> Returns the voltage average value in volts.

:MEASure[:SCALar]:VOLTage:HIGh →(Query)

Description	Returns the output voltage maximum peak value (Vmax).
 Note	Voltage maximum peak value is defined as the highest peak value in the complete period.
Query syntax	:MEASure[:SCALar]:VOLTage:HIGh?
Return parameter	<NR2> Returns the Vmax value in volts.

:MEASure[:SCALar]:VOLTage:LOW →(Query)

Description	Returns the output current minimum value (Vmin).
Note:	Voltage minimum value is defined as the lowest value in the complete period.
Query syntax	:MEASure[:SCALar]:VOLTage:LOW?
Return parameter	<NR2> Returns the Vmin value in volts.

:MEASure[:SCALar]: VOLTage:HARMonic[:RMS] →(Query)

Description	Returns 41 values covering Total and order 1 to 40 voltage (Vrms) in harmonic. (Only AC-INT and 50 /60 Hz Active)
Query syntax	:MEASure[:SCALar]: VOLTage:HARMonic[:RMS]?

Return	<NR2>,<NR2>,<NR2>,<NR2>..., etc.	Returns the entire 41 values containing Total and order 1 to 40 voltage (Vrms) in harmonic.
--------	----------------------------------	---

:MEASure[:SCALar]: VOLTage:HARMonic:RATio → Query

Description	Returns 41 values covering Total and order 1 to 40 voltage (Ratio) in harmonic. (Only AC-INT and 50 /60 Hz Active)
-------------	--

Query syntax :MEASure[:SCALar]: VOLTage:HARMonic:RATio?

Return	<NR2>,<NR2>,<NR2>,<NR2>..., etc.	Returns the entire 41 values containing Total and order 1 to 40 voltage (Ratio) in harmonic.
--------	----------------------------------	--

Set →

:MEASure:CONFigure:SENSing → Query

Description	Sets or queries the remote sense configuration. (Only AC-INT, DC-INT, AC-SYNC Mode and 100V, 200V Range and SIN Wave Shape and Time Slew Rate Mode Active)
-------------	--

Syntax :MEASure:CONFigure:SENSing {<bool>|OFF|ON}

Query Syntax :MEASure:CONFigure:SENSing?

Parameter	OFF 0	Turns the remote sense off.
	ON 1	Turns the remote sense on.

Return parameter <bool> Returns the status of remote sense.

Example :MEAS:CONF:SENS 0
Sets the remote sense off.

Memory Commands

:MEMory:RCL.....	64
:MEMory:SAV.....	64

:MEMory:RCL



Description	Recalls the settings from memory slot M0~M9. These memory slots are mapped to the preset settings. Equivalent to the *RCL command.	
Syntax	:MEMory:RCL {<NR1> MINimum MAXimum}	
Parameter	<NR1>	0~9
	MINimum	0
	MAXimum	9
Example	:MEMory:RCL Recall the settings to M1.	

:MEMory:SAV



Description	Saves the settings into memory slot M0 ~ M9. These memory slots are mapped to the preset settings. Equivalent to the *SAV command.	
Syntax	:MEMory:SAV {<NR1> MINimum MAXimum}	
Parameter	<NR1>	0~9
	MINimum	0
	MAXimum	9
Example	:MEMory:SAV 1 Save the settings to M1.	

Output Commands

:OUTPut[:STATe]		65
:OUTPut:PON		65
:OUTPut:PROTection:CLEar		66
:OUTPut:RELAy		66

:OUTPut[:STATe]

Set →

→ Query

Description	Sets or queries the output state of power source.	
Syntax	:OUTPut[:STATe] {<bool> OFF ON}	
Query Syntax	:OUTPut[:STATe]?	
Parameter	OFF 0	Turns the output off.
	ON 1	Turns the output on.
Return parameter	<bool>	Returns output status of the instrument.
Example	:OUTP 0	
	Sets power output off.	

Set →

→ Query

:OUTPut:PON

Description	Sets the output state at power-on.	
Syntax	:OUTPut:PON {<NR1> OFF ON SEQ SIM}	
Return Syntax	:OUTPut:PON?	
Parameter	<NR1>	0 ~ 3
	OFF 0	Disabled
	ON 1	Enabled
	SEQ 2	Sequence function
	SIM 3	Simulate function
Return parameter	<NR1>	Returns the selected output state at power-on from 0 to 3.

Example :OUTPut:PON 2
Sets sequence function on at power-on.

:OUTPut:PROTection:CLEar

Set →

Description The Command will clear alarms like Over Current, Over Peak Current, Output Over-Power, Output Short, Output Overvoltage, Sensing Voltage Error.

Syntax :OUTPut:PROTection:CLEar

Set →

:OUTPut:RELay

→ Query

Description Sets or queries the output relay of power source.

Syntax :OUTPut:RELay {<bool>|OFF|ON}

Query Syntax :OUTPut:RELay?

Parameter	OFF 0	Turns the output relay Disable.
	ON 1	Turns the output relay Enable.

Return parameter <bool> Returns output relay of the instrument.

Example :OUTP:REL 1
Sets output relay Enable.

Status Commands

:STATus:OPERation:CONDition.....	67
:STATus:OPERation:ENABle.....	68
:STATus:OPERation[:EVENT]	68
:STATus:OPERation:NTRansition.....	68
:STATus:OPERation:PTRansition	68
:STATus:QUEStionable[:EVENT].....	69
:STATus:QUEStionable:CONDition	69
:STATus:QUEStionable:ENABle	69
:STATus:QUEStionable:NTRansition	70
:STATus:QUEStionable:PTRansition	70
:STATus:PRESet.....	70
:STATus:WARning:CONDition	71
:STATus:WARning:ENABle.....	71
:STATus:WARning[:EVENT]	72
:STATus:WARning:NTRansition	72
:STATus:WARning:PTRansition	72
:STATus:LOCK:CONDition.....	73
:STATus:LOCK:ENABle	73
:STATus:LOCK[:EVENT]	73
:STATus:LOCK:NTRansition.....	73
:STATus:LOCK:PTRansition.....	74

:STATus:OPERation:CONDition

→ Query

Description	Queries the Operation Status register. This query will not clear the register.	
Syntax	:STATus:OPERation:CONDition?	
Return	<NR1>	Returns the bit sum of the Operation Condition register. (0~32767)

:STATus:OPERation:ENABle

Set →
→ Query

Description	Sets or queries the bit sum of the Operation Status Enable register.	
Syntax	:STATus:OPERation:ENABle <NR1>	
Query Syntax	:STATus:OPERation:ENABle?	
Parameter	<NR1>	0~32767
Return parameter	<NR1>	0~32767

:STATus:OPERation[:EVENT]

→ Query

Description	Queries the Operation Status Event register and clears the contents of the register.	
Syntax	:STATus:OPERation[:EVENT]?	
Return	<NR1>	Returns the bit sum of the Operation Status Event register.

:STATus:OPERation:NTRansition

Set →
→ Query

Description	Sets or queries the bit sum of the negative transition filter of the Operation Status register.	
Syntax	:STATus:OPERation:NTRansition <NR1>	
Query Syntax	:STATus:OPERation:NTRansition?	
Parameter	<NR1>	0~32767
Return parameter	<NR1>	0~32767

:STATus:OPERation:PTRansition

Set →
→ Query

Description	Sets or queries the bit sum of the positive transition filter of the Operation Status register.	
-------------	---	--

Syntax	:STATus:OPERation:PTRansition <NR1>
	:STATus:OPERation:PTRansition?

Parameter	<NR1>	0~32767
-----------	-------	---------

Return parameter	<NR1>	0~32767
------------------	-------	---------

:STATus:QUEStionable[:EVENT]

Description	Queries the bit sum of the Questionable Status Event register. This query will also clear the contents of the register.
-------------	---

Query Syntax	:STATus:QUEStionable[:EVENT]?
--------------	-------------------------------

Return parameter	<NR1>	0~32767
------------------	-------	---------

:STATus:QUEStionable:CONDition

Description	Queries the status (bit sum) of the Questionable Status register. This query will not clear the register.
-------------	---

Query Syntax	:STATus:QUEStionable:CONDition?
--------------	---------------------------------

Return parameter	<NR1>	0~32767
------------------	-------	---------

:STATus:QUEStionable:ENABle

Description	Sets or queries the bit sum of the Questionable Status Enable register.
-------------	---

Syntax	:STATus:QUEStionable:ENABle <NR1>
--------	-----------------------------------

Query Syntax	:STATus:QUEStionable:ENABle?
--------------	------------------------------

Parameter	<NR1>	0~32767
-----------	-------	---------

Return parameter	<NR1>	0~32767
------------------	-------	---------

:STATus:QUEStionable:NTRansition

Set →
→ Query

Description	Sets or queries the bit sum of the negative transition filter of the Questionable Status register.	
Syntax	:STATus:QUEStionable:NTRansition <NR1>	
Query Syntax	:STATus:QUEStionable:NTRansition?	
Parameter	<NR1>	0~32767
Return parameter	<NR1>	0~32767

:STATus:QUEStionable:PTRansition

Set →
→ Query

Description	Sets or queries the bit sum of the positive transition filter of the Questionable Status register.	
Syntax	:STATus:QUEStionable:PTRansition <NR1>	
Return Syntax	:STATus:QUEStionable:PTRansition?	
Parameter	<NR1>	0~32767
Return parameter	<NR1>	0~32767

:STATus:PRESet

Set →

Description	This command resets the ENABLE register, the PTRansition filter and NTRansition filter on the Operation Status, Questionable Status, Warning Status and System Lock Status Registers. The registers/filters will be reset to a default value.
-------------	---

Default Register/Filter Values	Setting
QUEStionable Status Enable	0x0000
QUEStionable Status Positive Transition	0x7FFF
QUEStionable Status Negative Transition	0x0000
Operation Status Enable	0x0000
Operation Status Positive Transition	0x7FFF

Operation Status Negative Transition	0x0000
WARNIng Status Enable	0x0000
WARNIng Status Positive Transition	0x7FFF
WARNIng Status Negative Transition	0x0000
System Lock Status Enable	0x0000
System Lock Status Positive Transition	0x7FFF
System Lock Status Negative Transition	0x0000

Summary: The Questionable Status Enable registers, the Operation Status Enable registers, Warning Status registers and System Lock Status registers are both reset to 0.

The Questionable Status, Operation Status, Warning Status and System Lock Status Positive Transition filters are all set high (0x7FFF) and the Negative Transition filters are all set low (0x0000). I.e., only positive transitions will be recognized for the Questionable Status, Operation Status, Warning Status and System Lock Status registers.

Syntax :STATus:PRESet

:STATus:WARNIng:CONDition

→ Query

Description Queries the Warning Status register. This query will not clear the register.

Syntax :STATus:WARNIng:CONDition?

Return <NR1> Returns the bit sum of the Warning Condition register. (0~32767)

Set →

:STATus:WARNIng:ENABle

→ Query

Description Sets or queries the bit sum of the Warning Status Enable register.

Syntax :STATus:WARNing:ENABle <NR1>

Query Syntax :STATus:WARNing:ENABle?

Parameter <NR1> 0~32767

Return parameter <NR1> 0~32767

:STATus:WARNing[:EVENT] 

Description Queries the Warning Status Event register and clears the contents of the register.

Syntax :STATus:WARNing[:EVENT]?

Return <NR1> Returns the bit sum of the Warning Status Event register.

:STATus:WARNing:NTRansition  

Description Sets or queries the bit sum of the negative transition filter of the Warning Status register.

Syntax :STATus:WARNing:NTRansition <NR1>

Query Syntax :STATus:WARNing:NTRansition?

Parameter <NR1> 0~32767

Return parameter <NR1> 0~32767

:STATus:WARNing:PTRansition  

Description Sets or queries the bit sum of the positive transition filter of the Warning Status register.

Syntax :STATus:WARNing:PTRansition <NR1>

:STATus:WARNing:PTRansition?

Parameter <NR1> 0~32767

Return parameter <NR1> 0~32767

:STATus:LOCK:CONDition

→ Query

Description	Queries the System Lock Status register. This query will not clear the register.
-------------	--

Syntax	:STATus:LOCK:CONDition?
--------	-------------------------

Return	<NR1>	Returns the bit sum of the System Lock Status register. (0~32767)
--------	-------	---

Set →

:STATus:LOCK:ENABLE

→ Query

Description	Sets or queries the bit sum of the System Lock Status Enable register.
-------------	--

Syntax	:STATus:LOCK:ENABLE <NR1>
--------	---------------------------

Query Syntax	:STATus:LOCK:ENABLE?
--------------	----------------------

Parameter	<NR1>	0~32767
-----------	-------	---------

Return parameter	<NR1>	0~32767
------------------	-------	---------

:STATus:LOCK[:EVENT]

→ Query

Description	Queries the System Lock Status Event register and clears the contents of the register.
-------------	--

Syntax	:STATus:LOCK [:EVENT]?
--------	------------------------

Return	<NR1>	Returns the bit sum of the System Lock Status Event register.
--------	-------	---

Set →

:STATus:LOCK:NTRansition

→ Query

Description	Sets or queries the bit sum of the negative transition filter of the System Lock Status register.
-------------	---


Syntax	:STATus:LOCK:NTRansition <NR1>
--------	--------------------------------

Query Syntax	:STATus:LOCK:NTRansition?
--------------	---------------------------

Parameter	<NR1>	0~32767
-----------	-------	---------

Return parameter <NR1> 0~32767

:STATus:LOCK:PTRansition



Description Sets or queries the bit sum of the positive transition filter of the System Lock Status register.

Syntax :STATus:LOCK:PTRansition <NR1>
:STATus:LOCK:PTRansition?

Parameter <NR1> 0~32767

Return parameter <NR1> 0~32767

System Function Commands

:SYSTem:BEEPer:STATe	76
:SYSTem:COMMUnicate:GPIB[:SELF]:ADDReSS	76
:SYSTem:COMMUnicate:LAN:DHCP	76
:SYSTem:COMMUnicate:LAN:DNS	77
:SYSTem:COMMUnicate:LAN:GATeway	77
:SYSTem:COMMUnicate:LAN:IPADdress	77
:SYSTem:COMMUnicate:LAN:MAC	78
:SYSTem:COMMUnicate:LAN:SMASk	78
:SYSTem:COMMUnicate:RLSTate	79
:SYSTem:COMMUnicate:SERial[:RECeive]	
:TRANsmit:BAUD	79
:SYSTem:COMMUnicate:SERial[:RECeive]	
:TRANsmit:BITS	80
:SYSTem:COMMUnicate:SERial[:RECeive]	
:TRANsmit:PARity	80
:SYSTem:COMMUnicate:SERial[:RECeive]	
:TRANsmit:SBITs	81
:SYSTem:COMMUnicate:TCPIp:CONTRol	82
:SYSTem:COMMUnicate:USB:FRONT:STATe	82
:SYSTem:COMMUnicate:USB:REAR:STATe	82
:SYSTem:CONFigure[:MODE]	82
:SYSTem:CONFigure:EXTio[:STATe]	83
:SYSTem:ERRor	83
:SYSTem:ERRor:ENABle	84
:SYSTem:HOLD:STATe	84
:SYSTem:IPKHold:TIME	84
:SYSTem:KLOCK	84
:SYSTem:REBoot	85
:SYSTem:SLEW:MODE	85
:SYSTem:VUNit	85

:SYSTem:BEEPer:STATe

Set →
→ Query

Description	Sets or queries the buzzer state on/off.	
Syntax	:SYSTem:BEEPer:STATe {<bool> OFF ON}	
Query Syntax	:SYSTem:BEEPer:STATe?	
Parameter	OFF 0	Turns the buzzer off.
	ON 1	Turns the buzzer on.
Return parameter	<bool>	Returns the buzzer status.

:SYSTem:COMMUnicate:GPIB[:SELF]:ADDRess

Set →
→ Query

Description	Sets or queries the GPIB address.	
Note:	The setting will only be valid after the power has been cycled.	
Syntax	:SYSTem:COMMUnicate:GPIB[:SELF]:ADDRess <NR1>	
Query Syntax	:SYSTem:COMMUnicate:GPIB[:SELF]:ADDRess?	
Parameter/Return	<NR1>	0~30
Example	SYST:COMM:GPIB:ADDR 15 Sets the GPIB address to 15.	

:SYSTem:COMMUnicate:LAN:DHCP

Set →
→ Query

Description	Turns DHCP on/off. Queries the DHCP status.	
Note:	The setting will only be valid after the power has been cycled.	
Syntax	:SYSTem:COMMUnicate:LAN:DHCP {<bool> OFF ON}	
Query Syntax	:SYSTem:COMMUnicate:LAN:DHCP?	
Parameter	OFF 0	DHCP off

ON | 1 DHCP on

Return parameter <bool> Returns the DHCP status.

Set →

:SYSTem:COMMunicate:LAN:DNS

→ Query

Description Sets or queries the DNS address.

Note The setting will only be valid after the power has been cycled.

Syntax :SYSTem:COMMunicate:LAN:DNS <string>

Query Syntax :SYSTem:COMMunicate:LAN:DNS?

Parameter/Return <string> DNS in string format ("mask")
Applicable ASCII characters: 20H to 7EHExample SYST:COMM:LAN:DNS "172.16.1.252"
Sets the DNS to 172.16.1.252.

Set →

:SYSTem:COMMunicate:LAN:GATeway

→ Query

Description Sets or queries the Gateway address.



Note

The setting will only be valid after the power has been cycled.

Syntax :SYSTem:COMMunicate:LAN:GATeway <string>

Query Syntax :SYSTem:COMMunicate:LAN:GATeway?

Parameter/Return <string> Gateway address in string format
("address")
Applicable ASCII characters: 20H to 7EHExample SYST:COMM:LAN:GAT "172.16.0.254"
Sets the LAN gateway to 172.16.0.254.

Set →

:SYSTem:COMMunicate:LAN:IPADdress

→ Query

Description Sets or queries LAN IP address.



Note

The setting will only be valid after the power has been cycled.

Syntax	:SYSTem:COMMunicate:LAN:IPADdress <string>
Query Syntax	:SYSTem:COMMunicate:LAN:IPADdress?
Parameter/Return	<string> LAN IP address in string format ("address") Applicable ASCII characters: 20H to 7EH
Example	SYST:COMM:LAN:IPAD "172.16.5.111" Sets the IP address to 172.16.5.111.

:SYSTem:COMMunicate:LAN:MAC

→ Query

Description	Returns the unit MAC address as a string. The MAC address cannot be changed.
Query Syntax	:SYSTem:COMMunicate:LAN:MAC?
Return parameter	<string> Returns the MAC address in the following format "FF-FF-FF-FF-FF-FF"
Example	SYST:COMM:LAN:MAC? 02-80-AD-20-31-B1 Returns the MAC address.

Set →

:SYSTem:COMMunicate:LAN:SMASk

→ Query

Description	Sets or queries the LAN subnet mask.
 Note	The setting will only be valid after the power has been cycled.
Syntax	:SYSTem:COMMunicate:LAN:SMASk <string>
Query Syntax	:SYSTem:COMMunicate:LAN:SMASk?
Parameter/Return	<string> Subnet mask in string format ("mask") Applicable ASCII characters: 20H to 7EH
Example	SYST:COMM:LAN:SMASk "255.255.0.0" Sets the LAN mask to 255.255.0.0.

:SYSTem:COMMunicate:RLSTate

Set →
→ Query

Description	Enables or disables local/remote state of the instrument.	
Syntax	:SYSTem:COMMunicate:RLSTate {LOCaL REMote RWLock LREMote}	
Query Syntax	:SYSTem:COMMunicate:RLSTate?	
Parameter/Return parameter	LOCaL	All keys are valid. This instrument is controlled by the front panel controls.
	REMote	All keys are invalid, except for the [local] key and the ability to turn the output off.
	RWLock	All keys are invalid. The instrument can only be controlled remotely.
	LREMote	All keys are valid. This instrument is controlled by the front panel controls and remotely.
Example	:SYST:COMM:RLST LOCAL Sets the operating mode to local.	

**:SYSTem:COMMunicate:SERial[:RECeive]
:TRANsmmit:BAUD**

Set →
→ Query

Description	Sets or queries the UART baud rate.	
 Note	The setting will only be valid after the power has been cycled.	
Syntax	:SYSTem:COMMunicate:SERial[:RECeive]:TRANsmmit :BAUD <NR1>	
Query Syntax	:SYSTem:COMMunicate:SERial[:RECeive]:TRANsmmit :BAUD?	
Parameter/Return	<NR1>	1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200

Example SYST:COMM:SER:TRAN:BAUD?
 9600
 Returns the baud rate settings.

:SYSTem:COMMunicate:SERial[:RECeive] 
 :TRANsmit:BITS 

Description Sets or queries the UART number of data bits.



Note

The setting will only be valid after the power has been cycled.

Syntax :SYSTem:COMMunicate:SERial[:RECeive]:TRANsmit
 :BITS <NR1>

Query Syntax :SYSTem:COMMunicate:SERial[:RECeive]:TRANsmit
 :BITS?

Parameter 0 7 bits

 1 8 bits

Return parameter +0 7 bits

 +1 8 bits

Example SYST:COMM:SER:TRAN:BITS?
 +1

Indicates that 8 data bits are used for the UART connection.

:SYSTem:COMMunicate:SERial[:RECeive] 
 :TRANsmit:PARity 

Description Sets or queries the parity of the UART connection.




Note

The setting will only be valid after the power has been cycled.

Syntax :SYSTem:COMMunicate:SERial[:RECeive]:TRANsmit
 :PARity {NONE|ODD|EVEN}

Query Syntax	:SYSTem:COMMunicate:SERial[:RECeive]:TRANsmit :PARity?	
Parameter	NONE	No parity
	ODD	Odd parity
	EVEN	Even parity
Return parameter	+0	No parity
	+1	Odd parity
	+2	Even parity
Example	SYST:COMM:SER:TRAN:PARity? +0 Indicates that no parity is used for the UART connection.	

:SYSTem:COMMunicate:SERial[:RECeive]
:TRANsmit:SBITs

 Set →
 →  Query

Description	Sets or queries the number of stop bits used for the UART connection.	
 Note	The setting will only be valid after the power has been cycled.	
Syntax	:SYSTem:COMMunicate:SERial[:RECeive]:TRANsmit :SBITs <NR1>	
Query Syntax	:SYSTem:COMMunicate:SERial[:RECeive]:TRANsmit :SBITs?	
Parameter	0	1 stop bit
	1	2 stop bits
Return parameter	+0	1 stop bit
	+1	2 stop bits
Example	SYST:COMM:SER:TRAN:SBITs? +1 Indicates that one stop bit is used for the UART connection.	

:SYSTem:COMMunicate:TCPIp:CONTRol → Query

Description	Queries the socket port number.
Query Syntax	:SYSTem:COMMunicate:TCPIp:CONTRol?
Return parameter	<NR1> 0000 ~ 9999
Example	SYST:COMM:TCP:CONT? 2268 Returns the socket port number.

:SYSTem:COMMunicate:USB:FRONT:STATe → Query

Description	Queries the front panel USB-A port state.
Query Syntax	:SYSTem:COMMunicate:USB:FRONT:STATe?
Return parameter	+0 <NR1>Absent +1 <NR1>Mass Storage

:SYSTem:COMMunicate:USB:REAR:STATe → Query


Description	Queries the rear panel USB-B port state.
Query Syntax	:SYSTem:COMMunicate:USB:REAR:STATe?
Return parameter	+0 <NR1>Absent +1 <NR1>Connected to the PC

:SYSTem:CONFigure[:MODE] Set → → Query

Description	Sets or queries the test mode for the power supply.
Syntax	:SYSTem:CONFigure[:MODE] {<NR1> CONTInuous SEQuence SIMulation} (SEQ is available for AC+DC-INT, AC-INT, DC-INT Modes, whilst SIM is available for AC+DC-INT Mode.)

Query Syntax	:SYSTem:CONFigure[:MODE]?	
Parameter	CONTinuous 0	Continuous mode (normal operating mode)
	SEQuence 1	Sequence mode
	SIMulation 2	Simulation mode
Return parameter	<NR1>	
	CONT	Continuous mode (normal operating mode)
	SEQ	Sequence mode
	SIM	Simulation mode

:SYSTem:CONFigure:EXTio[:STATe]



Description	Sets or queries the external control state on/off.	
Syntax	:SYSTem:CONFigure:EXTio[:STATe] {<bool> OFF ON}	
Query Syntax	:SYSTem:CONFigure:EXTio[:STATe]?	
Parameter	OFF 0	Turns the external control off.
	ON 1	Turns the external control on.
Return parameter	<bool>	Returns the external control status.

:SYSTem:ERRor



Description	Queries the error queue. The last error message is returned. A maximum of 32 errors are stored in the error queue.	
Query Syntax	:SYSTem:ERRor?	
Return parameter	<string>	Returns an error code followed by an error message as a single string.
Example	SYSTem:ERRor? -100, "Command error"	

:SYSTem:ERRor:ENABle

Set →

Description	Clears the Error Queue and enables all error messages to be placed in the System Error Queue.
-------------	---

Syntax	:SYSTem:ERRor:ENABle
--------	----------------------

:SYSTem:HOLD:STATe

Set →

→ Query

Description	Sets or queries the freeze hold state on/off.
-------------	---

Syntax	:SYSTem:HOLD:STATe {<bool> OFF ON}
--------	------------------------------------

Query Syntax	:SYSTem:HOLD:STATe?
--------------	---------------------

Parameter	OFF 0	Turns the freeze hold off.
-----------	---------	----------------------------

	ON 1	Turns the freeze hold on.
--	--------	---------------------------

Return parameter	<bool>	Returns the freeze hold status.
------------------	--------	---------------------------------

:SYSTem:IPKHold:TIME

Set →

→ Query

Description	Sets or queries the Ipeak hold time for peak current measurement when output on.
-------------	--

Syntax	:SYSTem:IPKhold:TIME {<NR1>}
--------	------------------------------

Query Syntax	:SYSTem:IPKhold:TIME?
--------------	-----------------------

Parameter	<NR1>	1~60,000
-----------	-------	----------

Example	:SYST:IPKH:TIME 10
---------	--------------------

	Sets the Ipeak hold time 10ms to measure when output on.
--	--

:SYSTem:KLOCK

Set →

→ Query

Description	Enables or disables the front panel key lock.
-------------	---

Syntax	:SYSTem:KLOCK {<bool> OFF ON}
--------	-------------------------------

Query Syntax	:SYSTem:KLOCK?
--------------	----------------

Parameter	OFF 0	Panel keys unlocked
	ON 1	Panel keys locked
Return parameter	<bool>	Returns the key lock status.


:SYSTem:REBoot


Description	Reboots the ASR system.
Syntax	:SYSTem:REBoot

:SYSTem:SLEW:MODE




Description	Sets or queries slew mode setting.	
Syntax	:SYSTem:SLEW:MODE {<bool> TIME SLOPe}	
Query Syntax	:SYSTem:SLEW:MODE?	
Parameter	TIME 0	Sets the Time mode.
	SLOPe 1	Sets the Slope mode.
Return parameter	<bool>	Returns the slew mode setting.
Example	:SYST:SLEW:MODE TIME Sets the Time mode for slew mode.	


:SYSTem:VUNit



Description	Sets or Queries the Unit of Voltage Setting in Specific Wave Shape(TRI or ARB)	
Syntax	:SYSTem:VUNit <bool> RMS P-P	
Query Syntax	:SYSTem:VUNit?	
Parameter	RMS 0	Sets V Unit (TRI, ARB) as rms
	P-P 1	Sets V Unit (TRI, ARB) as p-p
Return parameter	<bool>	Returns the V Unit(TRI, ARB) setting.

Example :SYSTem:VUNit?
 +1
 Returns the V Unit(TRI, ARB) setting.

Source Commands

[SOURce]:CURRent:LIMit:PEAK:HIGH	87
[SOURce]:CURRent:LIMit:PEAK:LOW	88
[SOURce]:CURRent:LIMit:RMS[:AMPLitude]...	88
[SOURce]:CURRent:LIMit:PEAK:MODE.....	89
[SOURce]:CURRent:LIMit:RMS:MODE.....	89
[SOURce]:FREQuency:LIMit:HIGH	90
[SOURce]:FREQuency:LIMit:LOW	90
[SOURce]:FREQuency[:IMMediate]	91
[SOURce]:FUNCTion[:SHAPE][:IMMediate]	91
[SOURce]:FUNCTion:THD:FORMat	92
[SOURce]:MODE	93
[SOURce]:PHASe:STARt:STATe	94
[SOURce]:PHASe:STOP:STATe.....	94
[SOURce]:PHASe:STARt[:IMMediate]	95
[SOURce]:PHASe:STOP[:IMMediate]	95
[SOURce]:READ	96
[SOURce]:VOLTage:RANGe	96
[SOURce]:VOLTage:LIMit:RMS.....	97
[SOURce]:VOLTage:LIMit:PEAK.....	97
[SOURce]:VOLTage:LIMit:HIGH.....	98
[SOURce]:VOLTage:LIMit:LOW	98
[SOURce]:VOLTage[:LEVel][:IMMediate]	
[:AMPLitude]	99
[SOURce]:VOLTage[:LEVel][:IMMediate]	
:OFFSet.....	99

[SOURce]:CURRent:LIMit:PEAK:HIGH



Description	Sets or queries the Ipk-High Limit parameter for the continuous operation mode.
Syntax	[SOURce]:CURRent:LIMit:PEAK:HIGH {<NR2> MINimum MAXimum}
Query Syntax	[SOURce]:CURRent:LIMit:PEAK:HIGH? [MINimum MAXimum]

Parameter	<NR2>	Ipk-High Limit in Arms.
	MINimum	Minimum settable peak current high limit
	MAXimum	Maximum settable peak current high limit
Return parameter	<NR2>	Returns the Ipk-High Limit value
Example	CURR:LIM:PEAK:HIGH? +42.0000 Returns the peak current high limit as +42.0A.	

Set →

[[:SOURce]:CURRent:LIMit:PEAK:LOW

→ Query

Description	Sets or queries the Ipk-Low Limit parameter for the continuous operation mode.	
Syntax	[:SOURce]:CURRent:LIMit:PEAK:LOW {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:CURRent:LIMit:PEAK:LOW? [MINimum MAXimum]	
Parameter	<NR2>	Ipk-Low Limit in Arms.
	MINimum	Minimum settable peak current low limit
	MAXimum	Maximum settable peak current low limit
Return parameter	<NR2>	Returns the Ipk-Low Limit value
Example	:CURR:LIM:PEAK:LOW? -42.0000 Returns the peak current low limit as -42.0A.	

Set →

[[:SOURce]:CURRent:LIMit:RMS[:AMPLitude]


→ Query

Description	Sets or queries the Irms parameter for the continuous operation mode.	
Syntax	[:SOURce]:CURRent:LIMit:RMS[:AMPLitude] {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:CURRent:LIMit:RMS[:AMPLitude]? [MINimum MAXimum]	

Parameter	<NR2>	Irms in A.
	MINimum	Minimum settable current
	MAXimum	Maximum settable current
Return parameter	<NR2>	Returns the Irms.
Example	:CURR:LIM:RMS? +10.5000 Returns the Irms setting.	



[:SOURce]:CURRent:LIMit:PEAK:MODE



Description	Sets or queries Ipk limit enabled or disabled.	
Syntax	[:SOURce]:CURRent:LIMit:PEAK:MODE {<bool> OFF ON}	
Query Syntax	[:SOURce]:CURRent:LIMit:PEAK:MODE?	
Parameter/ Return parameter	<bool>	OFF (0) ON (1)
	OFF 0	Ipk limit off
	ON 1	Ipk limit on
Example	:CURR:LIM:PEAK:MODE ON Sets Ipk limit enabled.	



[:SOURce]:CURRent:LIMit:RMS:MODE



Description	Sets or queries IRMS limit status.	
Syntax	[:SOURce]:CURRent:LIMit:RMS:MODE {<bool> OFF ON}	
Query Syntax	[:SOURce]:CURRent:LIMit:RMS:MODE?	
Parameter/ Return parameter	<bool>	OFF (0) ON (1)
	OFF 0	IRMS limit off
	ON 1	IRMS limit on
Example	:CURR:LIM:RMS:MODE ON Sets IRMS limit enabled.	

[:SOURce]:FREQuency:LIMit:HIGH

Set →

→ Query

Description	Sets or queries the frequency upper limit range. (Only AC+DC-INT or AC-INT or AC+DC-ADD or AC-ADD Active)	
Syntax	[:SOURce]:FREQuency:LIMit:HIGH {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:FREQuency:LIMit:HIGH? [INimum MAXimum]	
Parameter	<NR2>	Frequency in Hz.
	MINimum	Minimum settable frequency
	MAXimum	Maximum settable frequency
Return parameter	<NR2>	Returns the frequency limit
Example	FREQ:LIM:HIGH? +999.9000 Returns the frequency upper limit.	

Set →

→ Query

[:SOURce]:FREQuency:LIMit:LOW

Description	Sets or queries the frequency lower limit range. (Only AC+DC-INT or AC-INT or AC+DC-ADD or AC-ADD Active)	
Syntax	[:SOURce]:FREQuency:LIMit:LOW {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:FREQuency:LIMit:LOW? [INimum MAXimum]	
Parameter	<NR2>	Frequency in Hz.
	MINimum	Minimum settable frequency
	MAXimum	Maximum settable frequency
Return parameter	<NR2>	Returns the frequency limit

Example FREQ:LIM:LOW?
+1.0000
Returns the frequency lower limit.

[[:SOURce]:FREQuency[:IMMediate]

Set →
→ Query

Description	Sets or queries the frequency for the immediate trigger. (Only AC+DC-INT or AC-INT or AC+DC-ADD or AC-ADD Active)	
Syntax	[:SOURce]:FREQuency[:IMMediate] {<NR2>(HZ) MINimum MAXimum}	
Query Syntax	[:SOURce]:FREQuency[:IMMediate]? [MINimum MAXimum]	
Parameter/Return parameter	<NR2>	Frequency setting in Hz.
	MINimum	Minimum frequency
	MAXimum	Maximum frequency
Example	:FREQ 60 Sets the frequency of 60Hz.	

[[:SOURce]:FUNCTion[:SHAPE][:IMMediate]

Set →
→ Query

Description	Sets or queries the waveforms of power supply. (Not available for DC-INT, AC+DC-EXT and AC-EXT)	
Syntax	[:SOURce]:FUNCTion[:SHAPE][:IMMediate] {<NR1> ARB1 ARB2 ARB3 ARB4 ARB5 ARB6 ARB7 ARB8 ARB9 ARB10 ARB11 ARB12 ARB13 ARB14 ARB15 ARB16 SIN SQU TRI}	
Query Syntax	[:SOURce]:FUNCTion[:SHAPE][:IMMediate]?	
Parameter / Return parameter	<NR1>	From 0 – 18, which represent different waveforms, respectively.
	ARB1 0	Arbitrary wave 1
	ARB2 1	Arbitrary wave 2

ARB3 2	Arbitrary wave 3
ARB4 3	Arbitrary wave 4
ARB5 4	Arbitrary wave 5
ARB6 5	Arbitrary wave 6
ARB7 6	Arbitrary wave 7
ARB8 7	Arbitrary wave 8
ARB9 8	Arbitrary wave 9
ARB10 9	Arbitrary wave 10
ARB11 10	Arbitrary wave 11
ARB12 11	Arbitrary wave 12
ARB13 12	Arbitrary wave 13
ARB14 13	Arbitrary wave 14
ARB15 14	Arbitrary wave 15
ARB16 15	Arbitrary wave 16
SIN 16	Sin wave
SQU 17	Square wave
TRI 18	Triangle wave


Example :SOUR:FUNC:SHAP:IMM?
 TRI
 Returns the waveform as Triangle wave.

[[:SOURce]:FUNCTion:THD:FORMat

Set →
 → Query

Description	Sets or queries the THD format.	
Syntax	[:SOURce]:FUNCTion:THD:FORMat {<bool> IEC CSA}	
Query Syntax	[:SOURce]:FUNCTion:THD:FORMat?	
Parameter / Return parameter	<bool>	IEC (0) CSA (1)

	IEC 0	IEC THD format
	CSA 1	CSA THD format
Example	:SOUR:FUNC:THD:FORM?	
	IEC	
	Returns the THD format as IEC.	



[:SOURce]:MODE

Description	Sets or queries the output mode of power supply.	
Syntax	[:SOURce]:MODE {<NR1> ACDC-INT AC-INT DC-INT ACDC-EXT AC-EXT ACDC-ADD AC-ADD ACDC-SYNC AC-SYNC}	
Query Syntax	[:SOURce]:MODE?	
Parameter / Return parameter	<NR1>	From 0 – 8, which represent different output modes, respectively.
	ACDC-INT 0	AC+DC-INT
	AC-INT 1	AC-INT
	DC-INT 2	DC-INT
	ACDC-EXT 3	AC+DC-EXT
	AC-EXT 4	AC-EXT
	ACDC-ADD 5	AC+DC-ADD
	AC-ADD 6	AC-ADD
	ACDC-SYNC 7	AC+DC-SYNC
	AC-SYNC 8	AC-SYNC
Example	MODE? AC+DC-INT Returns the output mode as AC+DC-INT.	

[:SOURce]:PHASe:STARt:STATe

Set →
→ Query

Description	Sets or queries state of start phase. (Not available for DC-INT, AC+DC-EXT and AC-EXT)	
Syntax	[:SOURce]:PHASe:STARt:STATe {<bool> FREE FIXED}	
Query Syntax	[:SOURce]:PHASe:STARt:STATe?	
Parameter/ Return parameter	<bool> FREE 0 FIXED 1	FREE (0) FIXED (1) Start phase Free Start phase Fixed
Example	:PHAS:STAR:STAT? FREE Returns the state of start phase as Free.	

[:SOURce]:PHASe:STOP:STATe

Set →
→ Query

Description	Sets or queries state of stop phase. (Not available for DC-INT, AC+DC-EXT and AC-EXT)	
Syntax	[:SOURce]:PHASe:STOP:STATe {<bool> FREE FIXED}	
Query Syntax	[:SOURce]:PHASe:STOP:STATe?	
Parameter/ Return parameter	<bool> FREE 0 FIXED 1	FREE (0) FIXED (1) Start phase Free Start phase Fixed
Example	:PHAS:STOP:STAT? FIXED Returns the state of stop phase as Fixed.	

Set →
 → Query

[[:SOURce]:PHASe:STARt[:IMMediate]

Description	Sets or queries the start phase. (Not available for DC-INT, AC+DC-EXT and AC-EXT)	
Syntax	[:SOURce]:PHASe:STARt[:IMMediate] {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:PHASe:STARt[:IMMediate]? [MINimum MAXimum]	
Parameter/Return parameter	<NR2>	Start phase value
	MINimum	0°
	MAXimum	359.9 °
Example	:PHAS:STAR 0 Sets the starting phase to 0.	

Set →
 → Query

[[:SOURce]:PHASe:STOP[:IMMediate]

Description	Sets or queries the off phase of the waveform. (Not available for DC-INT, AC+DC-EXT and AC-EXT)	
Note:	Sets the off phase of the waveform after the output has been turned off.	
Syntax	[:SOURce]:PHASe:STOP[:IMMediate] {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:PHASe:STOP[:IMMediate]? [MINimum MAXimum]	
Parameter/Return parameter	<NR2>	Stop phase value
	MINimum	0 °
	MAXimum	359.9 °
Example	:PHAS:STOP 60 Sets the stop phase to 60.	

[:SOURce]:READ

→ Query

Description	Returns the measurement readouts.	
Query Syntax	[:SOURce]:READ?	
Return parameter	<Vrms>,<Vavg>,<Vmax>,<Vmin>,<Irms>,<Iavg>,<Imax>,<Imin>,<IpkH>,<P>,<S>,<Q>,<PF>,<CF>,<THDv>,<THDi>,<Freq>	<THDv>,<THDi> returns values in AC-INT mode only, whereas returns Invalid in other modes.
		<S>,<Q>,<PF>,<CF> returns Invalid in DC-INT mode.
		<Freq> returns values in AC+DC-Sync and AC-Sync modes only, whereas returns Invalid in other modes.
Example	:READ? >+0.3204,+0.0306,+0.1879,-0.5809,+0.0121, -0.0007, +0.0030, -0.0060, -0.0201, +0.0013, +0.0039, +0.0037, +0.3400, +1.1500, Invalid, Invalid, Invalid	

Set →

[:SOURce]:VOLTage:RANGe

→ Query

Description	Sets or queries the voltage range.	
Syntax	[:SOURce]:VOLTage:RANGe {<NR1> 100 200 AUTO}	
Query Syntax	[:SOURce]:VOLTage:RANGe?	
Parameter / Return parameter	<NR1>	From 0 - 2, which represent different voltage ranges, respectively.
	100 0	100V
	200 1	200V
	AUTO 2	AUTO (Only AC+DC-INT or AC-INT or DC-INT or AC+DC-sync or AC-sync Active)

Example :SOUR:VOLT:RANG?
200V
Returns the voltage range as 200V.

Set →

[:SOURce]:VOLTage:LIMit:RMS

→ Query

Description Sets or queries the voltage limit for the continuous operation mode. (Only AC-INT or AC-ADD or AC-Sync Active)

Syntax [:SOURce]:VOLTage:LIMit:RMS
{<NR2>|MINimum|MAXimum}

Query Syntax [:SOURce]:VOLTage:LIMit:RMS?
[MINimum|MAXimum]

Parameter	<NR2>	Vrms.
	MINimum	Minimum voltage limit
	MAXimum	Maximum voltage limit

Return parameter <NR2> Returns the voltage limit.

Example VOLT:LIM:RMS?
+350.0000
Returns the Vrms limit.

Set →

[:SOURce]:VOLTage:LIMit:PEAK

→ Query

Description Sets or Queries the Value of Vpp in Specific Mode(AC-INT or AC-ADD or AC-Sync) and Specific Wave Shape(TRI or ARB) and Specific V Unit(p-p)

Syntax [:SOURce]:VOLTage:LIMit:PEAK <NR2> | MINimum | MAXimum

Query Syntax [:SOURce]:VOLTage:LIMit:PEAK?
[MINimum | MAXimum]

Parameter	<NR2>	Vpp
-----------	-------	-----

	MINimum	Minimum Vpp limit
	MAXimum	Maximum Vpp limit
Return parameter	<NR2>	Returns the Vpp limit.
Example	VOLT:LIM:PEAK? +500.0000 Returns the Vpp limit.	

[[:SOURce]:VOLTage:LIMit:HIGH

Set →

→ Query

Description	Sets or queries the voltage high limit. (Only AC+DC-INT or DC-INT or AC+DC-ADD or AC+DC-Sync Active)	
Syntax	[:SOURce]:VOLTage:LIMit:HIGH {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:VOLTage:LIMit:HIGH? [MINimum MAXimum]	
Parameter	<NR2>	Voltage high limit
	MINimum	Minimum voltage high limit
	MAXimum	Maximum voltage high limit
Return parameter	<NR2>	Returns the voltage high limit.
Example	VOLT:LIM:HIGH? +500.0000 Returns the voltage high limit.	

Set →

→ Query

[[:SOURce]:VOLTage:LIMit:LOW

Description	Sets or queries the voltage low limit. (Only AC+DC-INT or DC-INT or AC+DC-ADD or AC+DC-Sync Active)	
Syntax	[:SOURce]:VOLTage:LIMit:LOW {<NR2> MINimum MAXimum}	

Query Syntax	[:SOURce]:VOLTage:LIMit:LOW? [MINimum MAXimum]	
Parameter	<NR2>	Voltage low limit
	MINimum	Minimum voltage low limit
	MAXimum	Maximum voltage low limit
Return parameter	<NR2>	Returns the voltage low limit.
Example	VOLT:LIM:LOW?	
	-500.0000	
	Returns the voltage low limit.	

[:SOURce]:VOLTage[:LEVel][:IMMediate]
[:AMPLitude]

Set →
→ Query

Description	Sets or queries the RMS voltage for the continuous operation mode. (Not available for DC-INT, AC+DC-EXT and AC-EXT)	
Syntax	[:SOURce]:VOLTage[:LEVel][:IMMediate][:AMPLitude] {<NR2>(V) MINimum MAXimum}	
Query Syntax	[:SOURce]:VOLTage[:LEVel][:IMMediate][:AMPLitude]? [MINimum MAXimum]	
Parameter/Return parameter	<NR2>	Vrms.
	MINimum	Minimum voltage
	MAXimum	Maximum voltage
Example	:VOLT 150.0	
	Sets the voltage to 150.0 ACV.	

[:SOURce]:VOLTage[:LEVel][:IMMediate]:OFFSet

Set →
→ Query

Description	Sets or queries the voltage offset value. (Only AC+DC-INT or DC-INT or AC+DC-ADD or AC+DC-Sync Active)
-------------	--

Syntax	[:SOURce]:VOLTage[:LEVel][:IMMediate]:OFFSet {<NR2>(V) MINimum MAXimum}	
Query Syntax	[:SOURce]:VOLTage[:LEVel][:IMMediate]:OFFSet? [MINimum MAXimum]	
Parameter/Return parameter	<NR2>	Voltage offset value
	MINimum	Minimum voltage offset value
	MAXimum	Maximum voltage offset value
Example	:VOLT:OFFS? +150.0000 Returns the voltage offset value as 150.0.	

Sequence Commands

[:SOURce]:SEQuence:CPARameter	101
[:SOURce]:SEQuence:CSTep	102
[:SOURce]:SEQuence:SPARameter	102
[:SOURce]:SEQuence:STEP	103
[:SOURce]:SEQuence:CONDition	104
:TRIGger:SEQuence:SElected:EXECute	104

[:SOURce]:SEQuence:CPARameter




Description	Sets the common parameters for the Sequence mode. Please see the user manual for a full description of each parameter (Only Sequence Mode Active).	
Syntax	[:SOURce]:SEQuence:CPARameter {<NR2>,<NR2>,<bool> OFF ON,<NR2>,<bool> OFF ON,<NR1> CONTInue END HOLD,<NR1>,<bool> OFF ON,<NR1>,<bool> OFF ON,<NR1>,<bool> OFF ON,<NR1>,<bool> OFF ON,<NR1>,<bool> OFF ON}	
Query Syntax	[:SOURce]:SEQuence:CPARameter?	
Parameter	<NR2>	Step Time
	<NR2>	On phase
	<bool> OFF ON FREE FIXED	On Phase settings: on (fixed) (1) / off (free) (0)
	<NR2>	Off phase
	<bool> OFF ON FREE FIXED	Off Phase settings: on (fixed) (1) / off (free) (0)
	<NR1> CONTInue END HOLD	Term settings: Continue(0)/End(1)/Hold(2)
	<NR1>	Jump step number (0 ~ 999)
	<bool> OFF ON	Jump on(1)/off(0)
	<NR1>	Jump Cnt (0~ 9999)

	<NR1>	Sync Code: LL(0) / LH(1) / HL(2) / HH(3)
	<NR1>	Branch1 (0 ~ 999)
	<bool> OFF ON	Branch1 on(1)/off(0)
	<NR1>	Branch2 (0 ~ 999)
	<bool> OFF ON	Branch2 on(1)/off(0)
	<bool>	Reserved (Fixed to 0)
Return parameter	<NR2>,<NR2>,<bool>,<NR2>,<bool>,<NR1>,<NR1>,<bool>,<NR1>,<NR1>,<bool>,<NR1>,<bool>,<bool>	
	Returns the common parameters in the following order: Step time, on phase, on phase on/off, off phase, off phase on/off, term settings, jump step number, jump on/off, jump count, code on/off, branch1, branch1 on/off, branch2, branch2 on/off, reserved on/off.	
Example1	:SEQ:CPAR 1,1,0,10,1,HOLD,10,1,0,1,0,0,0,0,0	
Example2	:SEQ:CPAR? +1.0000,+1.0,+0,+10.0,+1,HOLD,+10,+1,+0,+1,+0,+0, + 0,+0,+0	

[:SOURce]:SEQUence:CSTep

→ Query


Description	Returns the currently running step number (Only Sequence Mode Active).	
Query Syntax	[:SOURce]:SEQUence:CSTep?	
Return parameter	<NR1>	Current step number
Example	:SEQ:CSTep? +1	

Set →

[:SOURce]:SEQUence:SPARAmeter

→ Query

Description	Sets or queries the parameters for a specified step (Only Sequence Mode Active).
-------------	--

Syntax	[:SOURce]:SEQuence:SPARAmeter {<NR2>,<NR1> CONSt KEEp SWEEp,<NR2>,<NR1> CONSt KEEp SWEEp,<NR2>,<NR1> CONSt KEEp SW Eep,SIN,<NR1>}	
Query Syntax	[:SOURce]:SEQuence:SPARAmeter?	
Parameter	<NR2>	ACV setting
	<NR1> CONSt KEEp SWEEp	ACV mode: Constant(0) Keep(1) Sweep(2)
	<NR2>	DCV. Not applicable. This parameter will be ignored.
	<NR1> CONSt KEEp SWEEp	DCV mode: Constant(0) Keep(1) Sweep(2)
	<NR2>	Frequency
	<NR1> CONSt KEEp SWEEp	Frequency mode: Constant(0) Keep(1) Sweep(2)
	Waveform	ARB1 ARB2 ARB3 ARB4 ARB5 ARB6 ARB7 ARB8 ARB9 ARB 10 ARB11 ARB12 ARB13 ARB1 4 ARB15 ARB16 SIN SQU TRI
	<NR1>	Phase angle. Fixed to 0.
Return parameter	<NR2>,<NR1> CONSt KEEp SWEEp,<NR2>,<NR1> CONSt KEEp SWEEp,<NR2>,<NR1> CONSt KEEp SWEEp,ARB1 ARB2 ARB3 ARB4 ARB5 ARB6 AR B7 ARB8 ARB9 ARB10 ARB11 ARB12 ARB13 ARB 14 ARB15 ARB16 SIN SQU TRI,<NR1>	
	Returns the step parameters in the following order: ACV, ACV mode, DCV, DCV mode, frequency, frequency mode, wave, phase.	
Example	:SEQ:SPAR? +0.0,CONST,+0.0,CONST,+50.00,CONST,SIN,0	
	 	
	[:SOURce]:SEQuence:STEP	
Description	Sets or queries the current step number (Only Sequence Mode Active).	

Syntax	[:SOURce]:SEQUence:STEP {<NR1> MINimum MAXimum}	
Query Syntax	[:SOURce]:SEQUence:STEP? [MINimum MAXimum]	
Parameter/Return parameter	<NR1>	Step number
	MINimum	Minimum step number
	MAXimum	Maximum step number
Example	:SEQ:STEP 1 Sets the step number to 1.	

[:SOURce]:SEQUence:CONDition → Query

Description	Returns the sequence status.(Only Sequence Mode Active)		
Query Syntax	[:SOURce]:SEQUence:CONDition?		
Return parameter	<NR1>	Current sequence status	0 (Idle mode)
			1 (Run mode)
			2 (Hold mode)
Example	:SEQ:COND? 1		

:TRIGger:SEQUence:SELEcted:EXECute Set →

Description	Sets to execute actions for sequence mode. (Only Sequence Mode Active)		
Syntax	:TRIGger:SEQUence:SELEcted:EXECute {STOP START HOLD BRAN1 BRAN2}		
Parameter	STOP	Stops sequence execution	
	START	Starts sequence execution	
	HOLD	Holds sequence execution	
	BRAN1	Jumps to Branch 1 execution	
	BRAN2	Jumps to Branch 2 execution	

Example	TRIG:SEQ:SEL:EXEC STAR Starts sequence execution.
---------	--

Simulate Commands

[SOURce]:SIMulation:CONDition	107
[SOURce]:SIMulation:ABNormal:CODE	107
[SOURce]:SIMulation:ABNormal:FREQuency	108
[SOURce]:SIMulation:ABNormal:PHASe :START:ENABLE.....	108
[SOURce]:SIMulation:ABNormal:PHASe :START[:IMMediate]	109
[SOURce]:SIMulation:ABNormal:PHASe :STOP:ENABLE	109
[SOURce]:SIMulation:ABNormal:PHASe :STOP[:IMMediate]	110
[SOURce]:SIMulation:ABNormal:TIME	110
[SOURce]:SIMulation:ABNormal:VOLTage ...	111
[SOURce]:SIMulation:CSTep	111
[SOURce]:SIMulation:INITial:CODE	112
[SOURce]:SIMulation:INITial:FREQuency	112
[SOURce]:SIMulation:INITial:PHASe :START:ENABLE.....	113
[SOURce]:SIMulation:INITial:PHASe :START[:IMMediate]	113
[SOURce]:SIMulation:INITial:PHASe :STOP:ENABLE	114
[SOURce]:SIMulation:INITial:PHASe :STOP[:IMMediate]	114
[SOURce]:SIMulation:INITial:VOLTage	115
[SOURce]:SIMulation:NORMal<1 2>:CODE ..	115
[SOURce]:SIMulation:NORMal1:FREQuency ..	116
[SOURce]:SIMulation:NORMal<1 2> :PHASe:START:ENABLE	116
[SOURce]:SIMulation:NORMal<1 2> :PHASe:START[:IMMediate]	117
[SOURce]:SIMulation:NORMal<1 2> :PHASe:STOP:ENABLE	117
[SOURce]:SIMulation:NORMal<1 2> :PHASe:STOP[:IMMediate]	118
[SOURce]:SIMulation:NORMal<1 2>:TIME ...	118

[SOURce]:SIMulation:NORMal1:VOLTage.....	119
[SOURce]:SIMulation:REPeat:COUNt	119
[SOURce]:SIMulation:REPeat:ENABle	120
[SOURce]:SIMulation:TRANsition<1 2> :TIME.....	120
[SOURce]:SIMulation:TRANsition<1 2> :CODE	121
:TRIGger:SIMulation:SELected:EXECute	121

[SOURce]:SIMulation:CONDition

→ Query

Description	Returns the simulation status. (Only Simulation Mode Active)		
Query Syntax	[:SOURce]:SIMulation:CONDition?		
Return parameter	<NR1>	Current simulation status	0 (Idle mode)
			1 (Run mode)
			2 (Hold mode)
Example	:SIM:COND? 1		

Set →

[SOURce]:SIMulation:ABNormal:CODE

→ Query

Description	Sets the external trigger output for the abnormal step parameter. This option is only applicable when in the Simulation mode (Only Simulation Mode Active).		
Syntax	[SOURce]:SIMulation:ABNormal:CODE {<NR1> MINimum MAXimum}		
Query Syntax	[SOURce]:SIMulation:ABNormal:CODE? [MINimum MAXimum]		
Parameter/Return parameter	<NR1>	External trigger output, 0=LL, 1=LH, 2=HL, 3=HH.	
	MINimum	0 (LL)	

[:SOURce]:SIMulation:ABNormal:PHASe
:STARt[:IMMediate]

Set →
→ Query

Description	Sets or queries the ON Phs parameter of the abnormal step for the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:ABNormal:PHASe:STARt[:IMMediate] {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:SIMulation:ABNormal:PHASe:STARt[:IMMediate]? [MINimum MAXimum]	
Parameter/Return parameter	<NR2>	ON Phs (start phase)
	MINimum	0
	MAXimum	359.9
Example	:SIM:ABN:PHAS:STAR 0 Sets ON Phs to 0.	

[:SOURce]:SIMulation:ABNormal:PHASe
:STOP:ENABle

Set →
→ Query

Description	Enables/Disables (Fixed/Free) the OFF Phs parameter of the abnormal step for the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:ABNormal:PHASe:STOP:ENABle {<bool> OFF ON FREE FIXED }	
Query Syntax	[:SOURce]:SIMulation:ABNormal:PHASe:STOP:ENABle?	
Parameter/Return parameter	OFF 0 FREE	Disabled
	ON 1 FIXED	Enabled
Example	:SIM:ABN:PHAS:STOP:ENAB 1 Enable the OFF Phs.	

[:SOURce]:SIMulation:ABNormal:PHASe Set →
:STOP[:IMMediate] → Query

Description	Sets or queries the OFF Phs parameter of the abnormal step for the Simulation mode (Only Simulation Mode Active).	
 Note	Sets the off phase of the waveform after the output has been turned off.	
Syntax	[:SOURce]:SIMulation:ABNormal:PHASe:STOP[:IMMediate] {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:SIMulation:ABNormal:PHASe:STOP[:IMMediate]? [MINimum MAXimum]	
Parameter/Return parameter	<NR2>	OFF Phs (Stop phase)
	MINimum	0
	MAXimum	359.9
Example	:SIM:ABN:PHAS:STOP 0 Sets OFF Phs to 0.	

[:SOURce]:SIMulation:ABNormal:TIME Set →
 → Query

Description	Sets or queries the Time parameter of the abnormal step for the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:ABNormal:TIME {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:SIMulation:ABNormal:TIME? [MINimum MAXimum]	
Parameter/Return parameter	<NR2>	Time of the abnormal step in seconds
	MINimum	0.0001
	MAXimum	999.9999s
Example	:SIM:ABN:TIME 1 Sets the abnormal step time to 1 second.	

Set →
 → Query

[:SOURce]:SIMulation:ABNormal:VOLTage

Description	Sets or queries the Vset parameter of the abnormal step for the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:ABNormal:VOLTage {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:SIMulation:ABNormal:VOLTage? [MINimum MAXimum]	
Parameter/Return parameter	<NR2>	Voltage of the abnormal step.
	MINimum	Minimum settable voltage
	MAXimum	Maximum settable voltage
Example	:SIM:ABN:VOLT MAX Sets the abnormal step voltage to the maximum.	

[:SOURce]:SIMulation:CSTep → Query

Description	Returns the currently running step (Only Simulation Mode Active).	
Query Syntax	[:SOURce]:SIMulation:CSTep?	
Return parameter	<NR1>	Current step +0 = Initial step +1 = Normal1 step +2 = Transition1 step +3 = Abnormal step +4 = Transition2 step +5 = Normal2 step
Example	:SIM:CSTep? +1	

Set →
→ Query

[[:SOURce]:SIMulation:INITial:CODE

Description	Sets the external trigger output for the initial step parameter. This option is only applicable when in the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:INITial:CODE {<NR1> MINimum MAXimum}	
Query Syntax	[:SOURce]:SIMulation:INITial:CODE? [MINimum MAXimum]	
Parameter/Return parameter	<NR1>	0=LL, 1=LH, 2=HL, 3=HH
	MINimum	0 (LL)
	MAXimum	3 (HH)
Example	SIM:INIT:CODE 1	

Set →
→ Query

[[:SOURce]:SIMulation:INITial:FREQuency

Description	Sets or queries the frequency of the initial step of the simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:INITial:FREQuency {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:SIMulation:INITial:FREQuency? [MINimum MAXimum]	
Parameter/Return parameter	<NR2>	Frequency of initial step
	MINimum	Minimum frequency
	MAXimum	Maximum frequency
Example	:SIM:INIT:FREQ 60 Sets the frequency of the initial step to 60Hz.	

[:SOURce]:SIMulation:INITial:PHASe:STARt:ENABle Set →
→ Query

Description	Enables/Disables (Fixed/Free) the ON Phs parameter of the initial step for the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:INITial:PHASe:STARt:ENABLE {<bool> OFF ON FREE FIXED}	
Query Syntax	[:SOURce]:SIMulation:INITial:PHASe:STARt:ENABLE?	
Parameter/Return parameter	OFF 0 FREE	Disabled
	ON 1 FIXED	Enabled
Example	:SIM:INIT:PHAS:STAR:ENAB 1 Enable the ON Phs.	

[:SOURce]:SIMulation:INITial:PHASe:STARt[:IMMediate] Set →
→ Query

Description	Sets or queries the ON Phs parameter of the initial step for the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:INITial:PHASe:STARt[:IMMediate] {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:SIMulation:INITial:PHASe:STARt[:IMMediate]? [MINimum MAXimum]	
Parameter/Return parameter	<NR2>	ON Phs (start phase)
	MINimum	0
	MAXimum	359.9
Example	:SIM:INIT:PHAS:STAR 0 Sets ON Phs to 0.	

[[:SOURce]:SIMulation:INITial:PHASe:STOP
:ENABLE

Set →
→ Query

Description	Enables/Disables (Fixed/Free) the OFF Phs parameter of the initial step for the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:INITial:PHASe:STOP:ENABLE {<bool> OFF ON FREE FIXED}	
Query Syntax	[:SOURce]:SIMulation:INITial:PHASe:STOP:ENABLE?	
Parameter/Return parameter	OFF 0 FREE	Disabled
	ON 1 FIXED	Enabled
Example	:SIM:INIT:PHAS:STOP:ENAB 1 Enable the OFF Phs.	

[[:SOURce]:SIMulation:INITial:PHASe:STOP[:IM
Mediate]

Set →
→ Query

Description	Sets or queries the OFF Pha parameter of the initial step for the Simulation mode (Only Simulation Mode Active).	
 Note	Sets the off phase of the waveform after the output has been turned off.	
Syntax	[:SOURce]:SIMulation:INITial:PHASe:STOP[:IMMediate] {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:SIMulation:INITial:PHASe:STOP[:IMMediate]? [MINimum MAXimum]	
Parameter/Return parameter	<NR2>	OFF Phs (Stop phase)
	MINimum	0
	MAXimum	359.9
Example	:SIM:INIT:PHAS:STOP 0 Sets OFF Phs to 0.	

Set →
 → Query

[:SOURce]:SIMulation:INITial:VOLTage

Description	Sets or queries the Vset parameter of the initial step for the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:INITial:VOLTage {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:SIMulation:INITial:VOLTage? [MINimum MAXimum]	
Parameter/Return parameter	<NR2>	Voltage of the initial step.
	MINimum	Minimum settable voltage
	MAXimum	Maximum settable voltage
Example	:SIM:INIT:VOLT MAX Sets the initial step voltage to the maximum.	

Set →
 → Query

[:SOURce]:SIMulation:NORMal<1|2>:CODE

Description	Sets the external trigger output for the normal 1 or normal 2 step parameter. This option is only applicable when in the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:NORMal<1 2>:CODE {<NR1> MINimum MAXimum}	
Query Syntax	[:SOURce]:SIMulation:NORMal<1 2>:CODE? [MINimum MAXimum]	
Parameter/Return parameter	<NR1>	0=LL, 1=LH, 2=HL, 3=HH
	MINimum	0 (LL)
	MAXimum	3 (HH)
Example	SIM:NORM1:CODE 1	

[[:SOURce]:SIMulation:NORMal1:FREQuency (Set) →
→ (Query)

Description	Sets or queries the frequency of the normal1 step of the simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:NORMal1:FREQuency {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:SIMulation:NORMal1:FREQuency? [MINimum MAXimum]	
Parameter/Return parameter	1	Normal 1
	<NR2>	Frequency of abnormal step
	MINimum	Minimum frequency
	MAXimum	Maximum frequency
Example	:SIM:NORM1:FREQ 60 Sets the frequency to 60Hz.	

[[:SOURce]:SIMulation:NORMal<1|2>:PHASe:STARt:ENABle (Set) →
→ (Query)

Description	Enables/Disables (Fixed/Free) the ON Phs parameter of the normal1 or normal2 step for the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:NORMal<1 2>:PHASe:STARt:ENABle { <bool> OFF ON FREE FIXED}	
Query Syntax	[:SOURce]:SIMulation:NORMal<1 2>:PHASe:STARt:ENABle?	
Parameter/Return parameter	<1 2>	Normal 1 or Normal 2
	OFF 0 FREE	Disabled
	ON 1 FIXED	Enabled
Example	:SIM:NORM1:PHAS:STAR:ENAB 1 Enable the ON Phs.	

[:SOURce]:SIMulation:NORMal<1|2>
:PHASe:STARt[:IMMEDIATE]

Set →
→ Query

Description	Sets or queries the ON Phs parameter of the normal1 or normal2 step for the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:NORMal<1 2>:PHASe:STARt[:IMMEDIATE] {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:SIMulation:NORMal<1 2>:PHASe:STARt[:IMMEDIATE]? [MINimum MAXimum]	
Parameter/Return parameter	<1 2>	Normal 1 or Normal 2
	<NR2>	ON Phs (start phase)
	MINimum	0
	MAXimum	359.9
Example	:SIM:NORM1:PHAS:STAR 0 Sets ON Phs to 0.	

[:SOURce]:SIMulation:NORMal<1|2>
:PHASe:STOP:ENABLE

Set →
→ Query

Description	Enables/Disables (Fixed/Free) the OFF Phs parameter of the normal1 or normal2 step for the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:NORMal<1 2>:PHASe:STOP:ENABLE {<bool> OFF ON FREE FIXED}	
Query Syntax	[:SOURce]:SIMulation:NORMal<1 2>:PHASe:STOP:ENABLE?	
Parameter/Return parameter	<1 2>	Normal 1 or Normal 2
	OFF 0 FREE	Disabled
	ON 1 FIXED	Enabled
Example	:SIM:NORM1:PHAS:STOP:ENAB 1 Enable the OFF Phs.	

[[:SOURce]:SIMulation:NORMal<1|2>:PHASe:STOP[:IMMediate] (Set) →
→ (Query)

Description Sets or queries the OFF Phs parameter of the normal1 or normal2 step for the Simulation mode (Only Simulation Mode Active).



Note

Sets the off phase of the waveform after the output has been turned off.

Syntax [[:SOURce]:SIMulation:NORMal<1|2>:PHASe:STOP[:IMMediate] {<NR2>|MINimum|MAXimum}

Query Syntax [[:SOURce]:SIMulation:NORMal<1|2>:PHASe:STOP[:IMMediate]? [MINimum|MAXimum]

Parameter/Return parameter	<1 2>	Normal 1 or Normal 2
	<NR2>	OFF Phs (Stop phase)
	MINimum	0
	MAXimum	359.9

Example :SIM:NORM1:PHAS:STOP 0
Sets OFF Phs to 0.

[[:SOURce]:SIMulation:NORMal<1|2>:TIME (Set) →
→ (Query)

Description Sets or queries the Time parameter of the normal1 or normal2 step for the Simulation mode (Only Simulation Mode Active).

Syntax [[:SOURce]:SIMulation:NORMal<1|2>:TIME {<NR2>|MINimum|MAXimum}

Query Syntax [[:SOURce]:SIMulation:NORMal<1|2>:TIME? [MINimum|MAXimum]

Parameter/Return parameter	<1 2>	Normal 1 or Normal 2
	<NR2>	Time of the step in seconds
	MINimum	0.0001
	MAXimum	999.9999s

Example :SIM:NORM1:TIME 1
Sets the step time to 1 second.

[[:SOURce]:SIMulation:NORMal1:VOLTage]  


Description Sets or queries the Vset parameter of the normal1 step for the Simulation mode (Only Simulation Mode Active).

Syntax [:SOURce]:SIMulation:NORMal1:VOLTage
 {<NR2>|MINimum|MAXimum}

Query Syntax [:SOURce]:SIMulation:NORMal1:VOLTage?
 [MINimum|MAXimum]

Parameter/Return parameter	1	Normal 1
	<NR2>	Voltage of the abnormal step.
	MINimum	Minimum settable voltage
	MAXimum	Maximum settable voltage

Example :SIM:NORM1:VOLT MAX
Sets the normal1 step voltage to the maximum.

[[:SOURce]:SIMulation:REPeat:COUNt]  

Description Sets or queries the repeat count for the Simulation mode (Only Simulation Mode Active).

Syntax [:SOURce]:SIMulation:REPeat:COUNt
 {<NR1>|MINimum|MAXimum}

Query Syntax [:SOURce]:SIMulation:REPeat:COUNt?
 [MINimum|MAXimum]

Parameter/Return parameter	<NR1>	0 ~ 9999 (0 = infinite loop)
	MINimum	0
	MAXimum	9999

Example :SIM:REP:COUN 1
Sets the repeat count to 1.

Set →
→ Query

[[:SOURce]:SIMulation:REPeat:ENABle

Description	Turns the repeat function on or off for the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:REPeat:ENABle {<bool> OFF ON}	
Query Syntax	[:SOURce]:SIMulation:REPeat:ENABle?	
Parameter/Return parameter	OFF 0	Disabled
	ON 1	Enabled
Example	:SIM:REP:ENAB 1 Enables the repeat function.	

Set →
→ Query

[[:SOURce]:SIMulation:TRANsition<1|2>:TIME

Description	Sets or queries the Time parameter of the transition step for the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:TRANsition<1 2>:TIME {<NR2> MINimum MAXimum}	
Query Syntax	[:SOURce]:SIMulation:TRANsition<1 2>:TIME? [MINimum MAXimum]	
Parameter/Return parameter	<NR2>	Time of the step in seconds
	MINimum	0
	MAXimum	999.9999s
Example	:SIM:TRAN1:TIME 1 Sets the step time to 1 second.	

Set →
 → Query

[:SOURce]:SIMulation:TRANsition<1|2>:CODE

Description	Sets the external trigger output for the transition step parameter. This option is only applicable when in the Simulation mode (Only Simulation Mode Active).	
Syntax	[:SOURce]:SIMulation:TRANsition<1 2>:CODE {<NR1> MINimum MAXimum}	
Query Syntax	[:SOURce]:SIMulation:TRANsition<1 2>:CODE? [MINimum MAXimum]	
Parameter/Return parameter	<NR1>	0=LL, 1=LH, 2=HL, 3=HH
	MINimum	0 (LL)
	MAXimum	3 (HH)
Example	SIM:TRAN1:CODE 1	

:TRIGger:SIMulation:SElected:EXECute Set →

Description	Sets to execute actions for simulate mode (Only Simulation Mode Active).	
Syntax	:TRIGger:SIMulation:SElected:EXECute {STOP START HOLD}	
Parameter	STOP	Stops simulate execution
	START	Starts simulate execution
	HOLD	Holds simulate execution
Example	TRIG:SIM:SEL:EXEC STAR Starts simulate execution.	

Input Subsystem Command

:INPut:GAIN	122
:INPut:SYNC:SOURce	122

:INPut:GAIN

Set →

→ Query

Description	Sets or queries the input gain value. (Only AC+DC-EXT or AC-EXT or AC+DC-ADD or AC-ADD Active)
-------------	--

Syntax	:INPut:GAIN {<NR2>(V) MINimum MAXimum}
--------	--

Query Syntax	:INPut:GAIN? [MINimum MAXimum]
--------------	--------------------------------

Parameter/Return parameter	<NR2>	Input gain value
	MINimum	Minimum input gain value
	MAXimum	Maximum input gain value

Example	:INP:GAIN?
	+150.0000
	Returns the input gain value as 150.0.

Set →

→ Query

:INPut:SYNC:SOURce

Description	Sets or queries state of sync source. (Only AC+DC-sync or AC-sync Active)
-------------	---

Syntax	:INPut:SYNC:SOURce {<NR1> LINE EXT}
--------	-------------------------------------

Query Syntax	:INPut:SYNC:SOURce?
--------------	---------------------

Parameter/Return parameter	<NR1>	LINE (0) EXT (1)
	LINE 0	LINE sync source
	EXT 1	EXT sync source

Example :INP:SYNC:SOUR?
EXT
Returns the state of sync source as EXT.

Display Command

```
:DISPlay[:WINDow]:DESign:MODE ..... 124
:DISPlay[:WINDow]:MEASure:
SOURce<1 | 2 | 3> ..... 124
```

:DISPlay[:WINDow]:DESign:MODE



Description	Sets two display mode.	
Syntax	:DISPlay[:WINDow]:DESign:MODE{NORMal SIMPlE}	
Parameter	MORMal	Configure setup and Measurement.
	SIMPlE	All measurement times.
Example	:DISP:DES:MODE NORM Sets standard normal display.	

:DISPlay[:WINDow]:MEASure:SOURce<1|2|3>



Description	Sets standard normal display to measurement items 1 – 3.	
Syntax	:DISPlay[:WINDow]:MEASure:SOURce<1 3> { VRMS VAVG VMAX VMIN IRMS IAVG IMAX IMIN IPKH RPOWer SPOWer QPOWer FREQuency PFACTOR CFACtor THDV THDI}	
Parameter	Item 1	VRMS , VAVG , VMAX , VMIN , RPOWer , SPOWer*1, QPOWer*1, THDV*2
	Item 2	IRMS , IAVG , IMAX , IMIN , IPKH , PFACTOR*1, CFACtor*1, THDI*2
	Item 3	RPOWer , SPOWer*1, QPOWer*1, IPKH , PFACTOR*1, CFACtor*1, FREQuency*3
	Note	*1: Not available for DC-INT *2: Available for AC-INT only *3: Available for AC+DC-Sync & AC-Sync only

Example :DISP:MEAS:SOUR1 VRMS
Sets measurement source 1 VRMS display.

Status Register Overview

To program the ASR power supply effectively, the Status registers need to be understood. This chapter explains in detail how the Status registers are used and how to configure them.

Introduction to the Status Registers

Overview


The status registers are used to determine the status of the power supply. The status registers maintain the status of the protection conditions, operation conditions and instrument errors.

The ASR Series have a number of register groups:

- Questionable Status Register Group
- Standard Event Status Register Group
- Operation Status Register Group
- Warning Status Register Group
- System Lock Status Register Group
- Status Byte Register
- Service Request Enable Register
- Service Request Generation
- Error Queue
- Output Buffer

The diagram below shows the structure of the Status registers.


The Status Registers



Questionable Status Register Group

Overview

The Questionable Status Register Group indicates if any protection modes or limits have been tripped.



Bit Summary

Event	Bit #	Bit Weight
Output Overvoltage	0	1
Over internal maximum voltage (110% of rating voltage).		
Over Irms Current	1	2
Output current RMS value is excessive		
Overheat	4	16
Internal power stage over heat.		

Output Short	5	32
Call attention to output terminal short status.		
Over Ipeak+ Current or Over Ipeak- Current	6	64
Positive/Negative output current peak value is excessive.		
Fan Failure	7	128
Fan failure. Contact service center.		
Calibration Data Error	8	256
The calibration data is abnormal or out of allowance range.		
Output Over-Power	9	512
Over internal power stage maximum power (110% of rating power).		
IPK Limit	10	1024
The peak current limiter is activated.		
Remote Sensing Voltage Out of Range	11	2048
The Sensing voltage limiter is activated.		
IRMS Limit	12	4096
The RMS current limiter is activated.		
Always 0	15	32768

Condition Register	The Questionable Status Condition Register indicates the status of the power supply. If a bit is set in the Condition register, it indicates that the event is true. Reading the condition register does not change the state of the condition register.
--------------------	--

PTR/NTR Filters	The PTR/NTR (Positive/Negative transition) register determines the type of transition conditions that will set the corresponding bit in the Event Registers. Use the Positive transition filter to view events that change from false to positive, and use the negative transition filter to view events that change from positive to negative.
	Positive Transition 0→1
	Negative Transition 1→0


Event Register	The PTR/NTR Register will dictate the type of transition conditions will set the corresponding bits in the Event Register. If the Event Register is read, it will be cleared to 0.
----------------	--

Enable Register	The Enable register determines which Events in the Event Register will be used to set the QUES bit in the Status Byte Register.
-----------------	---

Operation Status Register Group

Overview

The Operation Status Register Group indicates the operating status of the power supply.



Bit Summary	Event	Bit #	Bit Weight
	Busy Status	1	2
	LOCK status (SYNC) status	8	256
	Hold Status(Sequence)	12	4096
	Run Status(Sequence)	14	16384
	Always 0	15	32768

Condition Register

The Operation Status Condition Register indicates the operating status of the power supply. If a bit is set in the Condition register, it indicates that the event is true. Reading the condition register does not change the state of the condition register.

PTR/NTR Filters	The PTR/NTR (Positive/Negative transition) register determines the type of transition conditions that will set the corresponding bit in the Event Registers. Use the Positive transition filter to view events that change from false to positive, and use the negative transition filter to view events that change from positive to negative.
-----------------	---

Positive Transition	0→1
---------------------	-----

Negative Transition	1→0
---------------------	-----


Event Register	The PTR/NTR Register will dictate the type of transition conditions will set the corresponding bits in the Event Register. If the Event Register is read, it will be cleared to 0.
----------------	--

Enable Register	The Enable register determines which registered Events in the Event Register will be used to set the OPER bit in the Status Byte Register.
-----------------	--

Warning Status Register Group

Overview

The Warning Status Register Group is a secondary protection status register for the supply output.



Bit Summary

Event	Bit #	Bit Weight
Output Overvoltage	0	1
Over internal maximum voltage (110% of rating voltage).		
Over Irms Current	1	2
Output current RMS value is excessive		
Over Ipeak+ Current or Over Ipeak- Current	3	8
Positive/Negative output current peak value is excessive.		
Overheat	6	64
Internal power stage over heat.		

	External Sync Frequency Error	7	128
	The external synchronization signal input frequency is out of the allowance range. (40Hz ~ 999.9Hz)		
	Sensing Voltage Error	9	512
	Remote sense connection wire is abnormal or over maximum compensation voltage.		
	Over Irms Current	10	1024
	Output current RMS value is excessive		
	Over Ipeak+ Current or Over Ipeak- Current	11	2048
	Positive/Negative output current peak value is excessive.		
	Output Over-Power	12	4096
	Over internal power stage maximum power (110% of rating power)		
	IRMS Limit	13	8192
	The RMS current limiter is activated.		
	IPK Limit	14	16384
	The peak current limiter is activated.		
	Always 0	15	32768
Condition Register	The System Lock Status Condition Register indicates the system lock status of the power supply. If a bit is set in the Condition register, it indicates that the event is true. Reading the condition register does not change the state of the condition register.		

PTR/NTR Filters	The PTR/NTR (Positive/Negative transition) register determines the type of transition conditions that will set the corresponding bit in the Event Registers. Use the Positive transition filter to view events that change from false to positive, and use the negative transition filter to view events that change from positive to negative.
-----------------	---

Positive Transition	0→1
---------------------	-----

Negative Transition	1→0
---------------------	-----


Event Register	The PTR/NTR Register will dictate the type of transition conditions will set the corresponding bits in the Event Register. If the Event Register is read, it will be cleared to 0.
----------------	--

Enable Register	The Enable register determines which registered Events in the Event Register will be used to set the WAR bit in the Status Byte Register.
-----------------	---

System Lock Status Register Group

Overview

The System Lock Status Register Group indicates if system lock protection modes have been tripped.



Bit Summary

Event	Bit #	Bit Weight
Power Input Anomaly	0	1
The power input voltage is insufficient or turning off main power switch. Check input power before rebooting the unit.		
Fan Failure	7	128
Fan failure. Contact service center.		
Startup Anomaly	8	256
Abnormal startup procedure.		

Condition Register	The System Lock Status Condition Register indicates the system lock status of the power supply. If a bit is set in the Condition register, it indicates that the event is true. Reading the condition register does not change the state of the condition register.
--------------------	---

PTR/NTR Filters	The PTR/NTR (Positive/Negative transition) register determines the type of transition conditions that will set the corresponding bit in the Event Registers. Use the Positive transition filter to view events that change from false to positive, and use the negative transition filter to view events that change from positive to negative.
	Positive Transition 0→1
	Negative Transition 1→0


Event Register	The PTR/NTR Register will dictate the type of transition conditions will set the corresponding bits in the Event Register. If the Event Register is read, it will be cleared to 0.
----------------	--

Enable Register	The Enable register determines which registered Events in the Event Register will be used to set the SLK bit in the Status Byte Register.
-----------------	---

Standard Event Status Register Group

Overview

The Standard Event Status Register Group indicates if any errors have occurred. The bits of the Event register are set by the error event queue.



Bit Summary


Event	Bit #	Bit Weight
OPC (Operation complete)	0	1
The OCP bit is set when all selected pending operations are complete. This bit is set in response to the *OPC command.		
RQC (Request control)	1	2
QUE (Query Error)	2	4
The Query Error bit is set in response to an error reading the Output Queue. This can be caused by trying to read the Output Queue when there is no data present.		

	DDE (Device Dependent Error)	3	8	
	Device specific error.			
	EXE (Execution Error)	4	16	
	The EXE bit indicates an execution error due to one of the following: illegal command parameter, parameter out of range, invalid parameter, the command didn't execute due to an overriding operation condition.			
	CME (Command Error)	5	32	
	The CME bit is set when a syntax error has occurred. The CME bit can also be set when a <GET> command is received within a program message.			
	URQ (User Request)	6	64	
	PON (Power On)	7	128	
	Indicates the power is turned on.			
Event Register	Any bits set in the event register indicate that an error has occurred. Reading the Event register will reset the register to 0.			
Enable Register	The Enable register determines which Events in the Event Register will be used to set the ESB bit in the Status Byte Register.			

Status Byte Register & Service Request Enable Register

Overview

The Status Byte register consolidates the status events of all the status registers. The Status Byte register can be read with the *STB? query and can be cleared with the *CLS command.



Bit Summary

Event	Bit #	Bit Weight
SLK(System Lock Status Register Summary)	0	1
WAR (Warning Status Register)	1	2
ERR (Error Queue not empty)	2	4
QUES (Questionable Status Register)	3	8
MAV (Message Available)	4	16
ESB(Standard Event Status Register Summary)	5	32

	RQS / MSS(Request Service / Master Summary Status)	6	64
	OPER (Operation Status Register)	7	128
Status Byte Register	Any bits set in the Status byte register acts as a summary register for all the three other status registers and indicates if there is a service request, an error in the Error Queue or data in the Output Queue. Reading the Status Byte register will reset the register to 0.		
Service Request Enable Register	The Service Request Enable Register controls which bits in the Status Byte Register are able to generate service requests.		

Error List

Command Errors

Overview

An <error/event number> in the range [-199 , -100] indicates that an IEEE 488.2 syntax error has been detected by the instrument's parser. The occurrence of any error in this class shall cause the command error bit (bit 5) in the event status register (IEEE 488.2, section 11.5.1) to be set. One of the following events has occurred:

- An IEEE 488.2 syntax error has been detected by the parser. That is, a controller-to-device message was received which is in violation of the IEEE 488.2 standard. Possible violations include a data element which violates the device listening formats or whose type is unacceptable to the device.
- An unrecognized header was received. Unrecognized headers include incorrect device-specific headers and incorrect or unimplemented IEEE 488.2 common commands.

Events that generate command errors shall not generate execution errors, device-specific errors, or query errors; see the other error definitions in this chapter.

Error Code	Description
-100 Command Error	This is the generic syntax error for devices that cannot detect more specific errors. This code indicates only that a Command Error as defined in IEEE 488.2,11.5.1.1.4 has occurred.

-102 Syntax error	An unrecognized command or data type was encountered; for example, a string was received when the device does not accept strings.
-103 Invalid separator	The parser was expecting a separator and encountered an illegal character; for example, the semicolon was omitted after a program message unit, MEAS:VOLT:DC?:MEASCURR:DC?
-104 Data type error	The parser recognized a data element different than one allowed; for example, numeric or string data was expected but block data was encountered.
-108 Parameter not allowed	More parameters were received than expected for the header; for example, the :SYSTem:KLOCK command only accepts one parameter, so receiving SYSTem:KLOCK 1,0 is not allowed.
-109 Missing parameter	Fewer parameters were received than required for the header; for example the :SYSTem:KLOCK command requires one parameter, so receiving :SYSTem:KLOCK is not allowed.
-111 Header separator error	A character which is not a legal header separator was encountered while parsing the header; for example, no white space followed the header, thus *SRE2 is an error.
-112 Program mnemonic too long	The header contains more than twelve characters (see IEEE 488.2, 7.6.1.4.1).
-113 Undefined header	The header is syntactically correct, but it is undefined for this specific device; for example, *XYZ is not defined for any device.

- 114 Header suffix out of range The value of a numeric suffix attached to a program mnemonic, see Syntax and Style section 6.2.5.2, makes the header invalid.
- 115 Unexpected number of parameters The number of parameters received does not correspond to the number of parameters expected. This is typically due an inconsistency with the number of instruments in the selected group.
- 120 Numeric data error This error, as well as errors -121 through -129, are generated when parsing a data element which appears to be numeric, including the non-decimal numeric types. This particular error message should be used if the device cannot detect a more specific error.
- 121 Invalid character in number An invalid character for the data type being parsed was encountered; for example, an alpha in a decimal numeric or a "9" in octal data.
- 128 Numeric data not allowed A legal numeric data element was received, but the device does not accept one in this position for the header.
- 131 Invalid suffix The suffix does not follow the syntax described in IEEE 488.2, 7.7.3.2, or the suffix is inappropriate for this device.
- 141 Invalid character data Either the character data element contains an invalid character or the particular element received is not valid for the header.
- 148 Character data not allowed A legal character data element was encountered where prohibited by the device.

-151 Invalid string data	A string data element was expected, but was invalid for some reason (see IEEE 488.2, 7.7.5.2); for example, an END message was received before the terminal quote character.
-158 String data not allowed	A string data element was encountered but was not allowed by the device at this point in parsing.
-160 Block data error	This error, as well as errors -161 through -169, are generated when parsing a block data element. This particular error message should be used if the device cannot detect a more specific error.
-161 Invalid block data	A block data element was expected, but was invalid for some reason (see IEEE 488.2, 7.7.6.2); for example, an END message was received before the length was satisfied.
-168 Block data not allowed	A legal block data element was encountered but was not allowed by the device at this point in parsing.
-178 Expression data not allowed	A legal expression data was encountered but was not allowed by the device at this point in parsing.

Execution Errors

Overview	An <error/event number> in the range [-299 , -200] indicates that an error has been detected by the instrument's execution control block. The occurrence of any error in this class shall cause the execution error bit (bit 4) in the event status register (IEEE 488.2, section 11.5.1) to be set. One of the following events has occurred: • A <PROGRAM DATA> element following a header was evaluated by the device as outside of its legal input range or is otherwise
----------	---

inconsistent with the device's capabilities.

- A valid program message could not be properly executed due to some device condition.

Execution errors shall be reported by the device after rounding and expression evaluation operations have taken place. Rounding a numeric data element, for example, shall not be reported as an execution error. Events that generate execution errors shall not generate Command Errors, device-specific errors, or Query Errors; see the other error definitions in this section.

Error Code	Description
-200 Execution error	This is the generic syntax error for devices that cannot detect more specific errors. This code indicates only that an Execution Error as defined in IEEE 488.2, 11.5.1.1.5 has occurred.
-201 Invalid while in local	Indicates that a command is not executable while the device is in local due to a hard local control (see IEEE 488.2, 5.6.1.5); for example, a device with a rotary switch receives a message which would change the switches state, but the device is in local so the message cannot be executed.
-203 Command protected	Indicates that a legal password-protected program command or query could not be executed because the command was disabled.
-211 Trigger ignored	Indicates that a GET, *TRG, or triggering signal was received and recognized by the device but was ignored because of device timing considerations; for example, the device was not ready to respond. Note: a DT0 device always ignores GET and treats *TRG as a Command Error.

-213 Init ignored	Indicates that a request for a measurement initiation was ignored as another measurement was already in progress.
-220 Parameter error	Indicates that a program data element related error occurred. This error message should be used when the device cannot detect the more specific errors described for errors -221 through -229.
-221 Settings conflict	Indicates that a legal program data element was parsed but could not be executed due to the current device state (see IEEE 488.2, 6.4.5.3 and 11.5.1.1.5.).
-222 Data out of range	Indicates that a legal program data element was parsed but could not be executed because the interpreted value was outside the legal range as defined by the device (see IEEE 488.2, 11.5.1.1.5.).
-224 Illegal parameter value	Used where exact value, from a list of possible, was expected.

Device Specific Errors

Overview	An <error/event number> in the range [-399 , -300] or [1 , 32767] indicates that the instrument has detected an error which is not a command error, a query error, or an execution error; some device operations did not properly complete, possibly due to an abnormal hardware or firmware condition. These codes are also used for self-test response errors. The occurrence of any error in this class should cause the device-specific error bit (bit 3) in the event status register (IEEE 488.2, section 11.5.1) to be set. The meaning of positive error codes is device-dependent and may be enumerated or bit mapped; the <error
----------	--

message>string for positive error codes is not defined by SCPI and available to the device designer.

Note that the string is not optional; if the designer does not wish to implement a string for a particular error, the null string should be sent (for example, 42,""). The occurrence of any error in this class should cause the device-specific error bit (bit 3) in the event status register (IEEE 488.2, section 11.5.1) to be set. Events that generate device-specific errors shall not generate command errors, execution errors, or query errors; see the other error definitions in this section.

Error Code	Description
-310 System error	Indicates that some error, termed “system error” by the device, has occurred. This code is device-dependent.
-320 Storage fault	Indicates that the firmware detected a fault when using data storage. This error is not an indication of physical damage or failure of any mass storage element.

Query Errors

Overview	An <error/event number> in the range [-499 , -400] indicates that the output queue control of the instrument has detected a problem with the message exchange protocol described in IEEE 488.2, chapter 6. The occurrence of any error in this class shall cause the query error bit (bit 2) in the event status register (IEEE 488.2, section 11.5.1) to be set. These errors correspond to message exchange protocol errors described in IEEE 488.2, section 6.5. One of the following is true:
----------	---

- An attempt is being made to read data from the output queue when no output is either present or pending;
- Data in the output queue has been lost.

Events that generate query errors shall not generate command errors, execution errors, or device-specific errors; see the other error definitions in this section.

Error Code	Description
-400 Query error	This is the generic query error for devices that cannot detect more specific errors. This code indicates only that a Query Error as defined in IEEE 488.2, 11.5.1.1.7 and 6.3 has occurred.

APPENDIX

Factory Default Settings

The following default settings are the factory configuration settings for the ASR-2000 series. For details on how to return to the factory default settings, please see the user manual.

AC+DC-INT Mode	ASR-2050	ASR-2050R	ASR-2100	ASR-2100R
Range	100V			
Wave Shape	SIN			
ACV	0.0 Vrms			
DCV	+0.0 Vdc			
FREQ	50.00 Hz			
IRMS	5.25 A		10.50 A	
V Limit	+/- 250.0 Vpp			
F Limit Lo	1.0 Hz			
F Limit Hi	999.9 Hz			
IPK Limit	+/- 21.00 A		+/- 42.00 A	
ON Phs	0.0°			
OFF Phs	0.0°			

AC-INT Mode	ASR-2050	ASR-2050R	ASR-2100	ASR-2100R
Range	100V			
Wave Shape	SIN			
ACV	0.0 Vrms			
FREQ	50.00 Hz			
IRMS	5.25 A		10.50 A	
V Limit	175.0 Vrms			
F Limit Lo	40.0 Hz			
F Limit Hi	999.9 Hz			
IPK Limit	+/- 21.00 A		+/- 42.00 A	
ON Phs	0.0°			
OFF Phs	0.0°			

DC-INT Mode	ASR-2050	ASR-2050R	ASR-2100	ASR-2100R
Range	100V			
DCV	0.0 Vdc			
I	5.25 A		10.50 A	
V Limit	+/- 250.0 Vpp			
IPK Limit	+/- 21.00 A		+/- 42.00 A	

AC+DC-EXT Mode	ASR-2050	ASR-2050R	ASR-2100	ASR-2100R
Range	100V			
GAIN	100.0			
IRMS	5.25 A		10.50 A	
IPK Limit	+/- 21.00 A		+/- 42.00 A	

AC-EXT Mode	ASR-2050	ASR-2050R	ASR-2100	ASR-2100R
Range	100V			
GAIN	100.0			
IRMS	5.25 A		10.50 A	
IPK Limit	+/- 21.00 A		+/- 42.00 A	

AC+DC-ADD Mode	ASR-2050	ASR-2050R	ASR-2100	ASR-2100R
Range	100V			
Wave Shape	SIN			
ACV	0.0 Vrms			
DCV	+0.0 Vdc			
GAIN	100.0			
FREQ	50.00 Hz			
IRMS	5.25 A		10.50 A	
V Limit	+/- 250.0 Vpp			
F Limit Lo	1.0 Hz			
F Limit Hi	999.9 Hz			
IPK Limit	+/- 21.00 A		+/- 42.00 A	
ON Phs	0.0°			
OFF Phs	0.0°			

AC-ADD Mode	ASR-2050	ASR-2050R	ASR-2100	ASR-2100R
Range	100V			
Wave Shape	SIN			
ACV	0.0 Vrms			
GAIN	100.0			

FREQ	50.00 Hz	
IRMS	5.25 A	10.50 A
V Limit	175.0 Vrms	
F Limit Lo	40.0 Hz	
F Limit Hi	999.9 Hz	
IPK Limit	+/- 21.00 A	+/- 42.00 A
ON Phs	0.0°	
OFF Phs	0.0°	

AC+DC-SYNC Mode	ASR-2050	ASR-2050R	ASR-2100	ASR-2100R
Range	100V			
Wave Shape	SIN			
ACV	0.0 Vrms			
DCV	+0.0 Vdc			
SIG	LINE			
IRMS	5.25 A		10.50 A	
V Limit	+/- 250.0 Vpp			
F Limit	999.9 Hz			
IPK Limit	+/- 21.00 A		+/- 42.00 A	
ON Phs	0.0°			
OFF Phs	0.0°			

AC-SYNC Mode	ASR-2050	ASR-2050R	ASR-2100	ASR-2100R
Range	100V			
Wave Shape	SIN			
ACV	0.0 Vrms			
SIG	LINE			
IRMS	5.25 A		10.50 A	
V Limit	175.0 Vrms			
F Limit	999.9 Hz			
IPK Limit	+/- 21.00 A		+/- 42.00 A	
ON Phs	0.0°			
OFF Phs	0.0°			

Menu	ASR-2000
T ipeak, hold(msec)	1 ms
IPK CLR	EXEC
Power ON	OFF
Buzzer	ON
Remote Sense	OFF

Slew Rate Mode	Slope
Output Relay	Enable
THD Format	IEC
External Control	OFF
V Unit (TRI, ARB)	rms

LAN	ASR-2000
DHCP	ON

USB Device	ASR-2000
Speed	Full

LCD Configuration	ASR-2000
LCD Contrast	50%
LCD Brightness	50%
LCD Saturation	50%

Sequence Mode	ASR-2000
Step	0
Time	0.1000 s
ACV	0.0, CT
DCV	0.0, CT
Fset	50.0, CT
Wave	SIN
Jump To	OFF
Jump Cnt	1
Branch 1	OFF
Branch 2	OFF
Term	CONTI
Sync Code	LL
ON Phs	Free
OFF Phs	Free

Simulation Mode	ASR-2000
Step	Initial
Repeat	OFF
Time	0.1000 s
ACV	0.0
Fset	50.00


ON Phs	Free
OFF Phs	Free
Wave	SIN
Code	LL

RS232C	Optional 1
Baudrate	9600
Databits	8bits
Parity	None
Stopbits	1bit


GPIB	Optional 1
Address	10

Default Waveform Setting


ARB 1 Ramp (rising)




ARB 2 Ramp (falling)




ARB 3 Sine wave, half-cycle(positive pole)




ARB 4 Sine wave, half-cycle(negative pole)




ARB 5 Sine wave, half-wave rectification (positive polarity)




ARB 6 Sine wave, half-wave
rectification(negative polarity)




ARB 7 Sine wave, full-wave
rectification(positive polarity)




ARB 8 Sine wave, full-wave
rectification(negative polarity)




ARB 9 Second order step response(damping coefficient 0.1)




ARB 10 Second order step response(damping coefficient 0.2)




ARB 11 Second order step response(damping coefficient 0.7)




ARB 12 Second order impulse
response(damping coefficient 0.1)




ARB 13 Second order impulse
response(damping coefficient 0.2)




ARB 14 Second order impulse
response(damping coefficient 0.7)



ARB 15 Exponential (rising)



ARB 16 Exponential (falling)




Note


Only FW version V1.12 above can support the function of default waveform Setting in Factory Default Settings.

Default Sequence Setting


SEQ6 Momentary drop in supply voltage




SEQ7 Reset test for Level1 systems with 12V



SEQ8 Starting Profile



SEQ9 Test2 Tr: 10ms, Td: 40ms



Note

Only FW version V1.12 above can support the function of Default Sequence Setting in Factory Default Settings.

I NDEX

Accessories	10
Caution symbol.....	4
Cleaning the instrument	6
Default settings	150
Disposal instructions.....	6
EN61010	
measurement category	5
pollution degree.....	6
Environment	
safety instruction	6
Ethernet	
interface	22
Front panel diagram.....	12
Ground	
symbol.....	4
List of features.....	9
Model differences	9
Power on/off	
safety instruction	5
Remote control	21

Command list	44
Command syntax.....	40
Error list	142
Ethernet.....	22
GPIO.....	31
LAN	22
RS232	25
Status registers	126
USB	23
Remote control function check	
GPIO.....	32
Realterm.....	28
RS-232.....	24, 27
USB	24, 27
Service operation	
about disassembly.....	5
Socket server function check	35
UK power cord.....	7
Warning symbol.....	4
Web server function check.....	34