



# 产品手册

# 仪器型号: SRS斯坦福低噪声电压放大器SR560

# 西安安泰测试科技有限公司

## 仪器维修|租赁|销售|测试

地址:西安市高新区纬二十六路 369 号 网址: <u>www.agitekservice.com</u> 电话: 400-876-5512 座机: 029-88827159

# **Low-Noise Voltage Preamplifier**

SR560 — DC to 1 MHz voltage preamplifier



- 4 nV/√Hz input noise
- 1 MHz bandwidth
- Variable gain from 1 to 50,000
- AC or DC coupled
- Two configurable signal filters
- Differential and single-ended inputs
- Line or battery operation
- RS-232 interface

### SR560 Low-Noise Preamplifier —

The SR560 is a high-performance, low-noise preamplifier that is ideal for a wide range of applications including low temperature measurements, optical detection, and audio engineering.

### Inputs

The SR560 has a differential front-end with 4 nV/ $\sqrt{Hz}$  input noise and an input impedance of 100 M $\Omega$ . Complete noise figure contours are shown in the SR560 Tech Note at the end of this section. The SR560's inputs are fully floating (BNC shields are not connected to chassis ground). Both the amplifier ground and the chassis ground are available on the rear panel for flexibility in grounding the instrument. Input offset nulling is accomplished by a front-panel potentiometer, accessible with a small screwdriver.

In addition to the signal inputs, a rear-panel TTL blanking input lets you quickly turn off and on the instrument's gain. This is useful in preventing front-end overloading. The gain turns off 5  $\mu$ s after the TTL level goes high, and back on again within 10  $\mu$ s after the TTL signal goes low.

### Outputs

Two insulated output BNC connectors provide 600  $\Omega$  and 50  $\Omega$  outputs. Both are capable of driving 10 Vpp into their respective loads. Two rear-panel power supply outputs



provide up to 200 mA of  $\pm 12$  VDC referenced to the amplifier ground. The outputs provide clean DC power for use as a bias source.

### Gain

Gain is selectable from 1 to 50,000 in a 1-2-5 sequence. An adjustable gain feature lets you specify the gain as a percentage of any of the fixed gain settings with 0.5 % resolution. Gain can be selectively allocated before the filters to optimize noise performance, or after the filters to reduce susceptibility to overloads.

### Filters

The SR560 contains two first-order RC filters whose cutoff frequency and type (HPF or LPF) can be configured from the front panel. Together, the filters can be configured as a 6 or 12 dB/oct rolloff low-pass or high-pass filter, or as a 6 dB/oct rolloff band-pass filter. A filter reset button is included to shorten the overload recovery time of the instrument when long filter time constants are being used. Filter cutoff frequencies can be set in a 1-3-10 sequence from 0.03 Hz to 1 MHz.

### **Battery Operation**

Three rechargeable lead-acid batteries provide up to 15 hours of battery powered operation. An internal battery charger automatically charges the batteries when the unit is connected to the line. The charger senses the battery state and adjusts the charging rate accordingly. Two rear-panel LEDs indicate the charge state of the batteries. When the batteries become discharged, they are automatically disconnected from the amplifier circuit to avoid battery damage.

### **No Digital Noise**

The microprocessor that runs the SR560 is "asleep" except during the brief interval it takes to change the instrument's setup. This ensures that no digital noise will contaminate lowlevel analog signals.

### **RS-232 Interface**

The RS-232 interface allows listen-only communication with the SR560 at 9600 baud. Up to four SR560s can be controlled from a single computer, with each SR560 being assigned a unique address. A "Listen" command specifies which SR560 will respond to commands on the RS-232 line. All functions of the instrument (except power on) can be set via the RS-232 interface. The RS-232 interface is opto-isolated from the amplifier circuitry to provide maximum noise immunity.





phone: (408)744-9040 www.thinkSRS.com

### Input

Input	
Inputs Input impedance Maximum input CMRR Noise Gain Gain stability Bandwidth Flatness	AC or DC coupled, single-ended or differential $100 M\Omega + 25 pF$ 3 Vpp 100 dB from DC to 1 kHz (100 mV common mode input at 1 kHz, gain of 100, low noise mode. Decreases by 6 dB/octave from 1 kHz to 1 MHz) $4 nV/\sqrt{Hz}$ at 1 kHz 1 to 50,000 in 1-2-5 sequence Vernier gain in 0.5% steps $200 ppm/^{\circ}C$ -3 dB at 1.2 MHz (typ.) $\pm 0.3 dB$ to 300 kHz (gains up to 1000)
Filters	
Signal filters Gain allocation	2 configurable (low-pass or high- pass) 6 dB/oct rolloff filters. -3 dB points are settable in a 1-3-10 sequence from 0.03 Hz to 1 MHz. High Dynamic Reserve — Gain is increased after the signal filters to prevent overloading. Low Noise — Gain is increased before the filters to improve noise figure.
Output	
Maximum output Filter reset DC drift	10 Vpp into $50 \Omega$ and $600 \Omega$ Long time constant filters may be reset with front-panel button. $5 \mu V/^{\circ}C$ referred to input (DC coupled)
Ordering InformationSR560Low-noise voltage preamplifier\$2595O560RMDDouble rack mount kit\$100O560RMSSingle rack mount kit\$100O560SBSpare battery set (3 batteries)\$200	
∿ LINE 48-58 Hz, FLSE 1A (100/1201/JG) or 120	

0.01% at 1kHz ±12 VDC @ 200 mA referenced to amplifier ground

### General

Distortion

Rear panel

External gating Interfaces Power

Dimensions Weight Warranty

TTL input sets gain to zero RS-232, 9600 baud, receive only 100/120/220/240 VAC, 6 W charged, 30 W while charging. Internal batteries provide 15 hours of operation between charges. Batteries are charged while connected to the line. 8.3" × 3.5" × 13.0" (WHD) 15 lbs. (batteries installed) One year parts and labor on defects in materials and workmanship















phone: (408)744-9040 www.thinkSRS.com